

NM OIL CONS. COMMISSION
Drawer DD
Artesia, NM 88210

Form 9-331
Dec. 1973

Form Approved.
Budget Bureau No. 42-R1424

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☒ well gas ☐ well other ☐
2. NAME OF OPERATOR
Harvey E. Yates Company
3. ADDRESS OF OPERATOR
P. O. Box 1933, Roswell, NM 88201
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 660' FSL & 1980 FWL
AT TOP PROD. INTERVAL:
AT TOTAL DEPTH: Same

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☒
REPAIR WELL ☐
PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
CHANGE ZONES ☒
ABANDON* ☐
(other) ☐

SUBSEQUENT REPORT OF:

☐
☐
☒
☐
☐
☐
☒
☐

5. LEASE

NM-13628

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Phillips Federal

9. WELL NO.

1

10. FIELD OR WILDCAT NAME

Wildcat -

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Section 1, T-24S, R-28E

12. COUNTY OR PARISH 13. STATE

Eddy

NM

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)

2963.3 GR

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

8/29/81 Pull tbg & RBP OOH. Run Elite CIBP on wireline and set @ 7470'.
Dump 35 linear feet cement w/wireline Bailer on CIBP. Plug off
Perfs 7493' to 7606'.

8/31/81 Set CIBP @ 6940' & Dump 35' cement on Top. Plug off Perfs 6954'
to 7081'. Set CIBP @ 6620'. Dump 35' cement on Top. Plug off
perfs 6631' to 6854'. Set CIBP @ 6460'. Release Wire line Unit.

9/01/81 Run Howco E-Z Drill cement retainer on 2 3/8" tbg. Set retainer
@ 6250'. Squeeze Perfs 6342' to 6421' w/150 sx Class "H" cement.
WOC 24 hours.

9/02 to 9/03/81 Run 3 3/4" Bit, casing scraper, 4-Drill Collars on 2 3/8" tubing.
Drill retainer @ 6250', drill out cement to CIBP @ 6460'. Test
Squeeze w/1500 psi for 30 min. Drill CIBP @ 6460' and clean out
to PBTD of 6585'. (On Back)

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED Park Harder TITLE Engineer DATE September 2, 1981

ACCEPTED FOR RECORD
(This space for Federal or State office use)
ROGER A. CHAPMAN

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

SEP 4 1981

U.S. GEOLOGICAL SURVEY
ROSWELL, NEW MEXICO

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

9/04/81 Pull & LD drilling tools. Perf 6455' to 6470'
w/2 JSPF. Total 30 holes. Set RBP @ 6475'
and RTTS Pkr @ 6435' & acidize w/1500 gals -
15% NE Acid.
9/05/81 Swab Test.