

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	<input checked="" type="checkbox"/>
FILE	<input checked="" type="checkbox"/>
U.S.G.S.	
LAND OFFICE	
OPERATOR	<input checked="" type="checkbox"/>

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

RECEIVED BY

DEC 21 1983

O. C. D.

ARTESIA, OFFICE

Form C-103
Revised 10-1-78

3a. Indicate Type of Lease

State ☐

Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator DINERO OPERATING COMPANY	8. Farm or Lease Name WILLIAMS
3. Address of Operator P. O. DRAWER 10505, MIDLAND, TEXAS 79702	9. Well No. 1
4. Location of Well UNIT LETTER N 1980 FEET FROM THE West LINE AND 660 FEET FROM THE South LINE, SECTION 25 TOWNSHIP 23-S RANGE 28-E NMPM.	10. Field and Pool, or WHdcat Bone Spring-S. Culebra Bluff
15. Elevation (Show whether DF, RT, CR, etc.) 2993.1 G.L.	12. County EDDY

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐

OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐

ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1503.

1. Pull out of hole with the tubing.
2. Set C.I.B.P. at 6,400':
3. Run in hole with tubing. Set plug (25 sacks) from 6400' to 6050'. (This will cover the top of Bone Spring at 6350').
4. Set plug (25 sacks) from 2650' to 2300'. (This will cover the top of the Delaware at 2600' and the 8 5/8" casing shoe at 2503').
5. Set plug (25 sacks) from 1350' to 1000'. WOC for 4 hours. Tag TOC.
6. Set plug (25 sacks) from 600' to 250'. (This will cover the 13 3/8" casing shoe at 422').
7. Set marker in 10 sacks of cement.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jim Beign TITLE ENGINEER DATE 12/19/83
APPROVED BY M. L. Williams TITLE OIL AND GAS INSPECTOR DATE JAN 04 1984
CONDITIONS OF APPROVAL, IF ANY:

Notary Public for the State of New Mexico

Plugging