

CISF  
8/2

Submit 3 Copies To Appropriate District  
Office  
District I  
1625 N. French Dr., Hobbs, NM 88240  
District II  
811 South First, Artesia, NM 87710  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico  
Energy, Minerals and Natural Resources  
OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

Form C-103  
Revised March 25, 1999

WELL API NO.

30-015-23907

5. Indicate Type of Lease

STATE ☐ FEE ☒

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name:

WILLIAMS

8. Well No.

1

9. Pool name or Wildcat

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

Oil Well ☐ Gas Well ☐ Other ☒ P & A

2. Name of Operator

Bird Creek Resources

3. Address of Operator

1437 S Boulder Suite 930 Tulsa Ok. 74119

4. Well Location

Union letter N : 660 feet from the S line and 1980 feet from the W line

Section 25

Township 23-S Range 28-E NMPM Eddy County

10. Elevation (Show whether DR, RKB, RT, GR, etc.)

2993 GL

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

Well to be P & A as soon as PU can be obtained.

1. Perforate 4 1/2" csg w/2 holes @ 450'.

2. Run 2 3/8" tbg and establish circulation down 4 1/2" csg & up 4 1/2" X 8 5/8" annulus. Lower tbg to 6000'.

3. Spot 26 sack cmt plug ("C" cmt, 4% bentonite, 1% CaCl) 6000'-5500'. Pull tbg to 5500'. Repeat 26 sack, 500' plugs until cmt is continuous from 6000' to 500'. Circ tbg clean & pull tbg.

4. Pump 100 sx "C" cmt down csg & up annulus, or until 4 1/2" csg & annulus are full of cmt. Install P & A marker. RDPV.

Notify OCD 24 hrs. prior to any work done

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Edward O. Holloway TITLE Engineer

DATE 9-25-01

Type or print name Edward O. Holloway

Telephone No 918-582-7713

(This space for State use)

APPROVED BY [Signature] TITLE Field Rep ID


DATE 10-5-01

Conditions of approval, if any:

Operator Bird Creek Res res  
Well Williams #1  
Unit N Section 25 Township 23 Range 28  
API # 30 -015 -23907

TOPS

Delaware	2600
Bone	6300



- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install Dry Hole Marker

Notify OCD 24 hrs. prior to any work done