

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	<input checked="" type="checkbox"/>
FILE	<input checked="" type="checkbox"/>
U.S.G.S.	
LAND OFFICE	<input checked="" type="checkbox"/>
OPERATOR	<input checked="" type="checkbox"/>

RECEIVED BY

JAN 23 1984

O. C. D.

ARTESIA, OFFICE

30-015-23972

5a. Indicate Type of Lease

State ☒Fee ☐

5. State Oil & Gas Lease No.

L-6707

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator DINERO OPERATING COMPANY	8. Farm or Lease Name Pubco State
3. Address of Operator Post Office Drawer 10505, Midland, Texas 79702	9. Well No. 1
4. Location of Well UNIT LETTER <u>A</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>East</u> LINE, SECTION <u>35</u> TOWNSHIP <u>24-S</u> RANGE <u>27-E</u> NMPM.	10. Field and Pool, or WHdcat Wildcat-Bone Spring
15. Elevation (Show whether DF, RT, GR, etc.) 3159.4 G.L.	12. County Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐PLUG AND ABANDON ☐TEMPORARILY ABANDON ☐PULL OR ALTER CASING ☐CHANGE PLANS ☐OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐COMMENCE DRILLING OPS. ☐CASING TEST AND CEMENT JOBS ☐OTHER ☐ALTERING CASING ☐PLUG AND ABANDONMENT ☒

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Pull rod & pump. Pull out of hole with tubing.
2. Set C.I.B.P. at 5,800'.
3. Set plug (25 sacks) from 5,800' to 5,450'. (This will cover the top of the Bone Spring at 5,800' and plug off perfs. from 5,890' to 6,249').
4. Circulated hole with mud.
5. Pulled 3042' of 4½" casing.
6. Set plug (50 sacks) from 3092' to 2912'. WOC for 4 hours. Tag TOC.
7. Set plug (100 sacks) from 2400' to 2000'. (This will cover 8 5/8" casing shoe at 2361').
8. Set plug (35 sacks) from 1100' to 996'. WOC for 4 hours. Tag TOC.
9. Set plug (35 sacks) from 450' to 350'. (This will cover 13 3/8" casing shoe at 416').
10. Set marker in 10 sacks of cement at surface.

Post II-2
1-21-84
YFA

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Lanada PamerTITLE Prod. SupervisorDATE Jan. 20, 1984APPROVED BY Harry BrooksTITLE GeologistDATE 2-22-85