

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

**SUNDRY NOTICES AND REPORTS ON WELLS**


(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well ☒ gas well ☐ other ☐  
2. NAME OF OPERATOR  
Ammex Petroleum, Inc.  
3. ADDRESS OF OPERATOR  
Box 10507 Midland, TX 79702  
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)  
AT SURFACE: 660 FNL & 660 FWL Sec. 14  
AT TOP PROD. INTERVAL: same  
AT TOTAL DEPTH: same

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:	SUBSEQUENT REPORT OF:
TEST WATER SHUT-OFF <input type="checkbox"/>	<input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	<input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	<input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	<input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	<input type="checkbox"/>
MULTIPLE COMPLETE <input type="checkbox"/>	<input type="checkbox"/>
CHANGE ZONES <input type="checkbox"/>	<input type="checkbox"/>
ABANDON* <input type="checkbox"/>	<input type="checkbox"/>
(other) Workover	


5. LEASE  
NM-18495  
6. IF INDIAN, ALLOTTEE OR TRIBE NAME  
7. UNIT AGREEMENT NAME  
8. FARM OR LEASE NAME  
Cedar Canyon  
9. WELL NO.  
1  
10. FIELD OR WILDCAT NAME  
Wildcat *Delaware*  
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 14, T24S, R29E  
12. COUNTY OR PARISH  
Eddy  
13. STATE  
New Mexico  
14. API NO.  
15. ELEVATIONS (SHOW DF, KDB, AND WD)  
2935 GR



17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Estimated date to start workover 9/21/83

1. Set retrievable BP @ 3950'± & cap w/cmt. Run tbg & pkr
2. Squeeze perfs 3860-80 w/250 sx "C"
3. Drill out & test, retrieve plug
4. Run CIBP to 5550' & set
5. Perf 5473-80 & 5482-90 w/1 jspf
6. RIH w/tbg & pkr & acidize w/500 gal 7½% acid & swab test
7. PU tbg & pkr to 5280'± & swab test
8. If necessary will acidize 5312-5490 w/2000 gal acid & 30 ball sealers
9. Prep to put well on pump



Subsurface Safety Valve: Manu. and Type \_\_\_\_\_ Set @ \_\_\_\_\_ Ft.

18. I hereby certify that the foregoing is true and correct


SIGNED *Peter W. Chester* TITLE Engineer DATE 9/20/83

APPROVED

(This space for Federal or State office use)

APPROVED BY (Orig. Sgd.) PETER W. CHESTER TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

DEC 9 1983



\*See Instructions on Reverse Side