

Form 3160-5
(November 1983)
(Formerly 9-331)

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

NM20359

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Enfield Federal

9. WELL NO.

#1

10. FIELD AND POOL, OR WILDCAT

N. W. Montlake - Delaware
Unders. Bone Spring

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec 17 - T24S - R28E

12. COUNTY OR PARISH 13. STATE

Eddy

NM

1. OIL ☒ CAS ☐
WELL WELL OTHER

2. NAME OF OPERATOR

Parker & Parsley Petroleum Company

3. ADDRESS OF OPERATOR

P.O. Box 3178, Midland, TX 79702

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.)
See also space 17 below.)
At surface

Unit Letter P, 660 FSL & 810 FEL
Sec 17 - T24S - R28E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, CM, etc.)

3054

JAN 26 1987

O. C. D.
ARTESIA, OFFICE

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZING

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(Note: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

- 1). Set CIBP at 5950' and cap with 35' of cement.
- 2). RIH with tubing to the CIBP. Mix mud using 25# of salt gel per bbl of 10# brine. Circ hole with mud.
- 3). Spot a 20 sack plug from 4450' - 4350' (DV Tool @ 4400').
- 4). Spot a 25 sack plug from 2600' - 2300' (Delaware 8 5/8" shoe).
- 5). Cut 4 1/2" casing at free point.
- 6). Spot an 85 sack plug from 1100' - 825' (DV Tool & salt section).
- 7). Spot a 35 sack plug from 475' - 375'.
- 8). Spot a 15 sack surface plug. Install dry hole marker.

Spot 100' plug at the stub, 50' in and 50' out

Per Armando Lopez 1-20-87

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Agent

DATE 1-15-87

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE 1-20-87

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side