Submit 3 Copies to Appropriate District Office

State of New Mexico Energy, Minerals and Natural Resources Department

Form	C-103	
Revie	ed 1-1-5	Š

DISTRICT I P.O. Box 1980, Hobbs, NM 88240

CONDITIONS OF APPROVAL, IF ANY:

AS NOTED ABOVE

OIL CONSERVATION DIVISION

P.O. Box 2088

Revised 1-1-8	5

WELL API NO. 30-015-25255 5. Indicate Type of Lease

Notify N.M.O.C.C. in sufficient time to witness

PLUGGING-

DISTRICT II P.O. Drawer DD, Artesia, NM \$8210 Santa Fe, New Mexico 87504-2088 FER X STATE DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410 6. State Oil & Gas Lease No. 168130 SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO: DEEPEN OR PLUG BACK TO A 7. Lease Name or Unit Agreement Name DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" DELTA FEE "B" (FORM C-101) FOR SUCH PROPOSALS.) Type of Well: WELL X WELL | COTA NO. 2. Name of Operator 8. Well No. Marathon Oil Company 3. Address of Operator 9. Pool name or Wildcat P.O. Box 552 Midland, Tx. 79702 **CARLSBAD EAST** 4. Well Location Unit Letter B : 990 Feet From The NORTH Line and 1980 Feet From The EAST Line ownship 22S Range 27E
/// 10. Elevation (Show whether DF, RKB, RT, GR, etc.) NMPM EDDY Township 22S Section 14 County GL: 3082' KB: 3110' Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: X PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK **ALTERING CASING CHANGE PLANS TEMPORARILY ABANDON** COMMENCE DRILLING OPNS. PLUG AND ABANDONMEN' **PULL OR ALTER CASING** CASING TEST AND CEMENT JOB OTHER: OTHER: 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. MARATHON OIL COMPANY IS PROPOSING TO P&A THIS WELL USING THE PROCEDURE SUMMARIZED BELOW: 1. MIRU. POOH W/ 2 3/8" TBG. SET CIBP @ 3,000'. DUMP 35' CMT ON TOP OF CIBP. LOAD HOLE W/10# BRINE W/25#/BBL GEL. 2. CUT 4 1/2" CSG @ FREEPOINT (TOC CALCULATED @ 2604'). PULL 4 1/2" CSG. 3. SET CMT PLUG 50' ABOVE AND BELOW STUB. IF 4 1/2" STUB IS BELOW 8 5/8" SHOE, SET CMT PLUG TO 50' ABOVE 8 5/8" SHOE. 30 545 € 2450. 196. 4. SET BALANCED CMT PLUG 1,735'-1,835' (50 SX). TAG PLUG. 5. SET BALANCED CMT PLUG 500'-400' (50 SX). TAG PLUG. 6. SET PLUG 50' TO SURFACE. CUT OFF CSG & INSTALL DRY HOLE MARKER. CLEAN LOCATION. RDMO. 7. 30 Sug & 2100' DELALIME 35 0x5 @ 225 MIT TOP. ALL PLYOS THIS AS EXECUTED HON ESTE I hereby certify that the information above is true and complete to the best of my knowledge and belief. ADVANCED ENGINEERING TECH. DATE 04-01-93 SIGNATURE ___ TELEPHONE NO.915-682-1626 TYPEORPRINT NAME THOMAS M. PRICE (This space for State Use)