

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO.  
30-015-25986

5. Indicate Type of Lease

STATE ☒

FEE ☐

6. State Oil & Gas Lease No.  
LG-5752

7. Lease Name or Unit Agreement Name

Ridge State

8. Well No.

1

9. Pool name or Wildcat  
Strawn

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL  
WELL ☐

GAS  
WELL ☒

OTHER

2. Name of Operator

R. E. Hibbert

3. Address of Operator

1500 Houston Club Bldg. Houston, TX 77002

4. Well Location

Unit Letter C : 360 Feet From The North Line and 1980 Feet From The West Line

Section 17

Township 24-S

Range 25-E

NMPM

Eddy

County

10. Elevation (Show whether DP, RKB, RT, GR, etc.)

4225' KB

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data  
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☒

REMEDIAL WORK ☐

ALTERING CASING ☐

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDONMENT ☐

PULL OR ALTER CASING ☒

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1.) Kill well with a viscous 9.0# fluid.
- 2.) Pull out of the hole with packer and tubing.
- 3.) Set a CIBP at 9975'±, cap with 35' (3 sacks) cement.
- 4.) Circulate hole with 10# mud.
- 5.) Set 100' plug at 9450' - 9550' (7 sacks) cement.
- 6.) Set 100' plug at 8500' - 8600' (7 sacks) cement.
- 7.) Perforate casing at 8600' and squeeze with (75 sacks) cement.
- 8.) Set a 100' plug at 4600' - 4700' (7 sacks) cement.
- 9.) Perforate casing at 4700' and squeeze with (75 sacks) cement.
- 10.) Cut casing at 2850', pull, and lay down.
- 11.) Set a 150' plug from 2850' - 2700' (60 sacks) cement. *Tag*
- 12.) Set a 100' plug from 1380' - 1480' (30 sacks) cement.

CONTINUED ON BACK

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE James F. O'Briant TITLE Agent for R. E. Hibbert

DATE 11/8/94  
9/12/94

TYPE OR PRINT NAME

TELEPHONE NO. (915) 683-551

(This space for State Use)

APPROVED BY Ray Smith TITLE OIL AND GAS INSPECTOR

DATE NOV 14 1994

CONDITIONS OF APPROVAL, IF ANY: