

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-015-25986
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. LG-5752
7. Lease Name or Unit Agreement Name Ridge State
8. Well No. 1
9. Pool name or Wildcat Strawn

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER	
2. Name of Operator R. E. Hibbert	
3. Address of Operator 1500 Houston Club Bldg. Houston, TX 77002	
4. Well Location Unit Letter <u>C</u> : <u>360</u> Feet From The <u>North</u> Line and <u>1980</u> Feet From The <u>West</u> Line Section <u>17</u> Township <u>24-S</u> Range <u>25-E</u> NMPM <u>Eddy</u> County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4225' KB	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input checked="" type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1.) Kill well with a viscous 9.0# fluid.
- 2.) Pull out of the hole with packer and tubing.
- 3.) Set a CIBP at 9975' - cap with 35' (3 sacks) cement.
- 4.) Circulate hole with 10# mud.
- 5.) Set 100' plug at 9450' - 9550' (7 sacks) cement.
- 6.) Set 100' plug at 8500' - 8600' (7 sacks) cement.
- 7.) Perforate casing at 8600' and squeeze with (75 sacks) cement.
- 8.) Set a 100' plug at 4600' - 4700' (7 sacks) cement.
- 9.) Perforate casing at 4700' and squeeze with (75 sacks) cement.
- 10.) Cut casing at 2850', pull, and lay down.
- 11.) Set a 150' plug from 2850' - 2700' (60 sacks) cement.
- 12.) Set a 100' plug from 1380' - 1480' (30 sacks) cement.

CONTINUED ON BACK

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE James F. O'Briant TITLE Agent for R. E. Hibbert DATE 11/8/94
TYPE OR PRINT NAME James F. O'Briant

TELEPHONE NO. (915) 683-5511

(This space for State Use)

APPROVED BY Ray Smith TITLE OIL FIELD SUPERVISOR DATE 11/14/94

CONDITIONS OF APPROVAL, IF ANY: