

JAMES "A" WELL NO. 7

61. RIH with SLM and tag fill. Clean out if necessary. Release packer and retrieve RBP at $\pm 5600'$. Reset RBP to $\pm 6850'$. Set packer and test RBP to 1000 psi. Dump 2 sx sand. COOH with 2-7/8" tubing, packer, and RBP.
62. GIH with 2-7/8", 6.5 lb/ft, EUE 8rd J-55 production tubing. Set tubing at $\pm 5400'$, SN at $\pm 5370'$ and tubing anchor at $\pm 5310'$ in 15,000 lbs tension. Remove BOP and NU wellhead.
63. GIH with pump and rod string. Place on production.