

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

RECEIVED

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

FEB - 4 1992

2. Name of Operator

Dinero Operating Company ✓

O. C. D.
ARTERIA OFFICE

3. Address and Telephone No.

P.O. Box 10505, Midland, Texas 79702

915/684-5544

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

710' FNL & 2,210' FWL,
Section 24, T-24-S, R-28-E, N.M.P.M.

5. Lease Designation and Serial No
NM-27919

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Dewey #3

9. API Well No.

30-015-26453X1

10. Field and Pool, or Exploratory Area

Malaga Delaware

11. County or Parish, State

Eddy County,
New Mexico

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☒ Recompletion
☒ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Rig up Pulling Unit, run log and will set wireline plug at 6,000' w/cement on top via Bailer.
Perforate 4 holes at 5,500' and will squeeze cement from 5,500' to 2,000' which will tie into 9 5/8" casing. Shut-In 24 hours.

Will go in with 2 3/8" tubing and spot 15% acid over zone that is to be perforated. Pull 2 3/8" tubing out of hole, go in with 4" casing gun and perforate 2 shots per foot at 2,740' to 2,780'. Acidize well with 2,000 gallons 15% acid and swab test well.

14. I hereby certify that the foregoing is true and correct

Signed Charlie [Signature]

Title Production Superintendent

Date 1/8/92

(This space for Federal or State office use)

Approved by _____
Conditions of approval, if any:

Title _____

Date 1/31/92