Submit 3 Copies to Appropriate District Office

APPROVED BY ---

CONDITIONS OF APPROVAL, IF ANY:

## State of New Mexico Energy, Minerals and Natural Resources Department

Form C-103 Revised 1-1-89

DISTRICT I P.O. Box 1980, Hobbs, NM 88240

OIL CONSERVATION DIVISION

P.O. Box 2088

26796 WELL API NO. 30-015-26790

\_ DATE -

DISTRICT II Santa Fe, New Mexico 8/504-2088 P.O. Drawer DD, Artesia, NM 88210	5. Indicate Type of Lease STATE X FEE
DISTRICT III 1000 Rio Brazos Rd., Aztec, NM 87410	6. State Oil & Gas Lease No.
SUNDRY NOTICES AND REPORTS ON WELLS  ( DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  (FORM C-101) FOR SUCH PROPOSALS.)	7. Lease Name or Unit Agreement Name  Sueno 15
1. Type of Well:  OIL GAS WELL X OTHER	bucke 15
2. Name of Operator  Nearburg Producing Company	8. Well No.
3. Address of Operator P.O. Box 823085, Dallas, TX 75382-3085	9. Pool name or Wildcat Delaware Wildcat
4. Well Location  Unit Letter E: 660 Feet From The West Line and 25	00 Feet From The North Line  NMPM Eddy County
Section 15 Township F Range 2/E  10. Elevation (Show whether DF, RKB, RT, GR, etc.)  3,097.2 GR	
11. Check Appropriate Box to Indicate Nature of Notice, R	Report, or Other Data
NOTICE OF INTENTION TO:	SSEQUENT REPORT OF:
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK	ALTERING CASING
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLIN	
PULL OR ALTER CASING CASING TEST AND C	EMENT JOB .
OTHER: OTHER:	
<ol> <li>Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, incl. work) SEE RULE 1103.</li> <li>Notify OCD</li> </ol>	uding estimated date of starting any proposed Prof ID-2 4-26-96 R4 Pt
<ol> <li>MIRU pulling unit &amp; come out hole with tbg.</li> <li>Go in hole with 5½ wire line B.P. set 4750 cap w/25 sk.</li> <li>Circulate hole with 10# gel mud</li> </ol>	cement
6. Cut csg. at 2000 ft. Casing would not move, went in hol	
tag plug at 1900 ft. 7. Cut csg. 1500 ft. & lay down, went in the hole w/tbg. to tag plug at 1400 ft.	
8. Lay down tbg. to 500 ft. spot 35 sk. plug tag plug at 42 9. Lay down tbg. & pump 10 sk. surface plug, cut well head, 10. Clean location, rig down.	install P/A marker
I hereby certify that the information above is true and complete to the best of my knowledge and belief.  SIGNATURE  TITLE	Jupt. DATE 3/6/91 TELEPHONE NO. 505/307
TYPE OR PRINT NAME H. R. Willis	4186

\_ TITLE -