Submit 3 Copies To Appropriate District	State of New Mexico Energy, Minerals and Natural Resources OIL CONSERVATION DIVISION 2040 South Pacheco Santa Fe, NM 87505			Form C-103				
Office District 1				Revised March 25, 1999				
1625 N. French Dr., Hobbs, NM 88240				WELL API NO.				
District II				30-015-20222				
811 South First, Artesia, NM 88210 District III				5. Indicate Type	of Lease			
1000 Rio Brazos Rd., Aztec, NM 87410				STATE				
District IV 2040 South Pacheco, Santa Fe, NM 87505				6. State Oil & C	as Lease No.			
2040 South Pacheco, Santa Fe, NM 87505								
SUNDRY NOTIC	7. Lease Name of	r Unit Agreement Na	me:					
(DO NOT USE THIS FORM FOR PROPOSA DIFFERENT RESERVOIR. USE "APPLICA								
PROPOSALS.)	McKenna Fede	rai						
1. Type of Well:								
Oil Well 🔲 Gas Well 🗌	Other - SWD							
2. Name of Operator	8. Well No.							
Limark Corporation	002							
3. Address of Operator	9. Pool name or Wildcat							
P.O. Box 10708, Midland, Texas	96100 S.W.D. ; Delaware							
4. Well Location								
		• •		220 6-46-4		P		
Unit Letter_M:	330 reet from the	South	ime and		m inewest	line		
Section 18	Township	265	Range 30E	NMPM Ede	iy County	_		
10. Elevation (Show whether DR, RKB, RT, GR, etc.) 3042' GL								
11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data								
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:								
PERFORM REMEDIAL WORK			REMEDIAL WOR		ALTERING CASIN	G 🗆		
	CHANGE PLANS		COMMENCE DRI	LLING OPNS. 🗖	PLUG AND ABANDONMENT			
PULL OR ALTER CASING	MULTIPLE		CASING TEST A					
	COMPLETION		CEMENT JOB					
OTHER:			OTHER:					

 Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

<u>Casing Repair as required by failed MIT</u>. Plan to pull tubing and packer. Pick up workstring and run in hole with retreivable bridgeplug and set at 3237'. Pull out of hole and run in hole with AD-1 packer to 1500'. Set packer and test for hole. Isolate hole. Dump 2 sx of sand on top of bridgeplug. Squeeze hole in casing with 100 sx Class 'C' cement with 2% CaCl leaving 75' above hole in casing. Pull tubing and wait on cement (minimum overnight). Run in hole with 3 7/8" drill bit and drill collars. Drill out cement squeeze and test casing. Wash sand off of bridgeplug. Pull and lay down workstring. Run in hole with injection packer to 3327'. Set packer and nipple up wellhead. Perform MIT with chart. Notify NMOCD concerning test.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.								
SIGNATURE		President	DATE_08/22/2000					
Type or print name Mark A. Philpy		Telephone No. 915 / 684	-5765 (office) 915/684-5959 (fax)					
(This space for State use)								
APPPROVED BY $\underline{Re(or(O_2))}$ Conditions of approval, if any:	TITLE		DATE					