

N. M. O. C. C. COPY
UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN DUPLICATE*
(Other instructions on reverse side)Copy to SF
Form approved.
Budget Bureau No. 42-R1424.
5. LEASE DESIGNATION AND SERIAL NO.

NM-0503

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Cotton Draw Unit

9. WELL NO.

68

10. FIELD AND POOL, OR WILDCAT

Undesignated

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 12, T-25-S, R-31-E

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

TEXACO Inc.

3. ADDRESS OF OPERATOR

P. O. Box 728 - Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface:

Well is located 2310' from the North Line and 1980' from the West Line of Section 12, T-25-S, R-31-E, Unit Letter "F", Eddy County, New Mexico.

11. PERMIT NO.

Regular

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3457' (DF)

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATING

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and vertical depths for all markers and zones pertinent to this work.) *

Total Depth 16,868'

Plug Back Total Depth 14,798'

9-5/8" OD 53.50# and 47# casing set @ 12,650'

7-5/8" OD 39# P-110 Liner set from 12,270' to 14,680'

5-1/2" OD 23# C-75 Liner set from 14,276' to 16,456'

1. Set cement retainer @ 16,300' and squeeze open hole 16,456' - 16,868' w/60 Sx. Class "H" cement. Plug Back Total Depth 16,300'. Job complete 11:30 PM, May 17, 1970
2. Set Otis WC packer @ 14,600'.
3. Ran 14,571' (453 joints) - 2-7/8" OD 6.50# (82 joints - 2670')
3-1/2" OD 9.30# (285 joints - 9275')
3-1/2" OD 10.30# (86 joints - 2626')
4. Set tubing in packer @ 14,600'.
5. Perforate 5-1/2" OD Liner w/2 JSPF from 14,940' - 14,954' and 14,959' - 14,992'. Test. Pull tubing.
6. Set CIBP @ 14,798' and packer @ 14,150'. PBTD 14,798'.
7. Ran 14,120' (437 joints) 2-7/8" and 3-1/2" OD tubing and set in packer @ 14,150'.
8. Perforate 5-1/2" OD Liner w/4 JSPF from 14,731' - 14,750' and 14,759' - 14,763'.
9. Acidize perforations 14,731' - 14,763' w/1000 gals 15% NE Acid w/scale inhibitors and 20% alcohol followed w/1000 gals MA w/scale inhibitor and 20% Alcohol. Follow w/1000 gals 7-1/2% NE Acid w/scale inhibitor and 20% Alcohol. Flush w/brine water.
10. Test and place well on production.

18. I hereby certify that the foregoing is true and correct

SIGNED

(This space for Federal or State office use)

Assistant District

TITLE Superintendent

DATE June 23, 1970

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

ACCEPTED FOR RECORD PURPOSES
JUN 26 1970
ACTING District Engineer

*See Instructions on Reverse Side