

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ gas ☒ other ☐

2. NAME OF OPERATOR  
Coquina Oil Corporation

3. ADDRESS OF OPERATOR  
P.O. Drawer 2960, Midland, Texas 79702

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)  
AT SURFACE: 1900' FSL & 1675 FEL  
AT TOP PROD. INTERVAL:  
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA.

REQUEST FOR APPROVAL TO:

TEST WATER SHUT-OFF ☐  
FRACTURE TREAT ☐  
SHOOT OR ACIDIZE ☐  
REPAIR WELL ☐  
PULL OR ALTER CASING ☐  
MULTIPLE COMPLETE ☐  
CHANGE ZONES ☐  
ABANDON\* ☒  
(other) ☐

SUBSEQUENT REPORT OF:

☐  
☐  
☐  
☐  
☐  
☐  
☐  
☐

5. LEASE

ARTESIA, OFFICE

NI-5476

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME  
Monsanto Federal

9. WELL NO.  
1

10. FIELD OR WILDCAT NAME  
Wildcat - Wolfcamp

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA  
Sec. 9, T26S, R23E

12. COUNTY OR PARISH  
Eddy

13. STATE  
New Mexico

14. API NO.  
3001520824

15. ELEVATIONS (SHOW DF, KDB, AND WD)  
GL-4338

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Completed 5-30-73. Has been shut-in since 5-73. No market.  
P&A instructions via Larry Brooks on September 20, 1984.

1. Set CIBP in 4 1/2 csg at 6475' with 35' cmt on top of BP.
2. Set 100' cmt plug in 4 1/2" across top of Wolfcamp from 6000'-6100'.
3. Run free point, cut & pull 4 1/2 casing.
4. Run 150' cmt plug in and out of top of 4 1/2 csg. stub. Tag plug.
5. Set 100' cmt plug across top of Bone Springs from 3000-3100.
6. Set 100' cmt plug across base of 8 5/8 from 727'-827'.
7. Remove wellhead. Run tubing and spot 50' cmt plug in top of 8 5/8. Install DHM.
8. Clean and level location and restore.

Subsurface Safety Valve: Manu. and Type \_\_\_\_\_ Set @ \_\_\_\_\_ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED J. B. Taylor TITLE Superintendent DATE 10-11-84

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE 10-29-84  
CONDITIONS OF APPROVAL, IF ANY: