

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

RECEIVED

1. CIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	OCT - 1 1991	7. UNIT AGREEMENT NAME Ross Draw
2. NAME OF OPERATOR J.C. Williamson ✓	O. C. D.	8. FARM OR LEASE NAME Ross Draw Unit
3. ADDRESS OF OPERATOR P.O. Box 16 Midland, Texas 79702	ARTESIA OFFICE	9. WELL NO. 4
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1980' FNL & 1980' FWL		10. FIELD AND POOL, OR WILDCAT Ross Draw Delaware
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3001.1' GR	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 27-T-26-S, R-30-E
		12. COUNTY OR PARISH Eddy
		13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETION <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input checked="" type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>

(Other) Plugging Procedure

SUBSEQUENT REPORT OF:

WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input type="checkbox"/>

(Other) _____
(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

- 1) Set CIBP @ 3400' w/35' cement on top of BP.
- 2) Shot off 4-1/2 @ 3000'±, top cmt reported @ 3298', pull & lay down 4-1/2".
- 3) Set 100' plug across base of salt & stabilize 4-1/2" from 2950'-3050', tag same; if not taggable, reset.
- 4) Set 100' plug from 1900'-2000' across bottom stub of 7" pipe.
- 5) Try to pull 10-3/4" pipe @ 700', if not, tieback pipe & pull what we can, at least 500' should be free, shoot, pull and lay down 10-3/4" pipe.
- 6) Set 150' plug from 450-600', tag plug, reset if not holding.
- 7) Ascertain status of 13-3/8" pipe, set @ 280' w/50sx cement.
- 8) Set 100' plug from 230'-330'.
- 9) Attempt to get 1" pipe around 13-3/8" to 50' and re-cement surface csg., if not, clean out cellar and put ready mix around as much of surface casing as possible, mixing ready mix w/small pea gravel.
- 10) Put 50' plug in top of 13-3/8", cut off 13-3/8" pipe at bottom of cellar.
- 11) Erect dry hole marker and clean up location.
- 12) Rehabilitate location.

18. I hereby certify that the foregoing is true and correct

SIGNED

REN Jan Pfister

TITLE Agent

DATE 09/25/91

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE 9/27/91

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side