

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NOV 03 1980

O. C. D.
ANTHONY OFFICE

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
L-4687	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

OIL ☐ GAS ☒ OTHER ☐

1. Name of Operator
Amoco Production Company

2. Address of Operator
P. O. Box 68 Hobbs, NM 88240

3. Location of Well
UNIT LETTER L, 1980 FEET FROM THE South LINE AND 660 FEET FROM THE West LINE, SECTION 15 TOWNSHIP 25-S RANGE 28-E NMPM.

7. Unit Agreement Name

8. Farm or Lease Name
State GG Com.

9. Well No.
1

10. Field and Pool, or Wildcat
Bone Springs

15. Elevation (Show whether DF, RT, GR, etc.)

2988.3 GL

12. County

Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐

ALTERING CASING ☐
PLUG AND ABANDONMENT ☐
OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon well per the following:

Pull 2-7/8" tubing, packer and tailpipe. Spot 35' Class H cement on top of cast iron bridge plug set at 8850'. Set a cast iron bridge plug at 7500'. Cap with 35' Class H cement. Set a 100' Class H cement plug from 6250'-6350'. Set a 100' Class H cement plug from 2480'-2580'. Run free point to determine where to cut 9-5/8" casing. Top of cement estimated to be at 2108'. Cut and pull casing from above free point (at approx. 2100'). Spot a 100' Class H cement plug - 50' in and 50' out of the 9-5/8" casing stub at approx. 2100'. Spot a 100' Class H cement plug from 350'-450' inside the 13-3/8" casing across the 20" casing shoe. Spot a 20-SX Class H cement surface plug and weld cap on and install P X A marker.

0+4-NMOCD, A 1-Hou 1-Susp 1-LBG 1-W. Stafford, Hou

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Benton Green

TITLE Assist. Admin. Analyst

DATE 10-31-80

APPROVED BY W.A. Gressitt

TITLE SUPERVISOR, DISTRICT II

DATE NOV 04 1980

CONDITIONS OF APPROVAL, IF ANY: