

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

Form approved.  
Budget Bureau No. 1004-0135  
Expires August 31, 1985

45F

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

RECEIVED

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR J.C. Williamson		8. FARM OR LEASE NAME Sun Ex Sun EX Federal Unit
3. ADDRESS OF OPERATOR PO Box 16 Midland, TX 79702		9. WELL NO. 1
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 810' FSL and 1665' FWL		10. FIELD AND POOL, OR WILDCAT East Brushy Draw Delaware
14. PERMIT NO. 30-015-25582		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 10, T-26S, R-30E
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3119.5' GR		12. COUNTY OR PARISH Eddy
		13. STATE NM

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>	WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETE <input type="checkbox"/>	FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input checked="" type="checkbox"/>	SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	(Other) <input type="checkbox"/>	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

- (1) Set CIBP @ 4450± and put 35' cement on top of plug.
- (2) Place 100' cement plug inside 5 1/2" casing from 3478'-3378', do not tag plug (shoe of 8 5/8" casing @ 3428')
- (3) Cut 5 1/2" casing @ 3200'±, lay down same.
- (4) Put 150' cement plug @ stub of 5 1/2" casing, 75' in and out of stub, do not tag plug.
- (5) Freepoint 9 5/8" casing, cut and lay down casing. 2000' 9 5/8" expected to be recovered.
- (6) Set 150' cement plug, 75' in and out of 9 5/8" casing, plug to be tagged.
- (7) Set 100' cement plug from 870'-770', plug to be tagged. (shoe of 13 3/8" casing @ 820')
- (8) Put 50' surface plug at top of surface pipe.
- (9) Erect dry hole marker, clean location, remove all pipe and equipment from the location as soon as conveniently possible.
- (10) Restore and reseed location as per BLM specifications. (procedure discussed and approved by Shannon Shaw, BLM, Carlsbad on 6-29-88)

RECEIVED  
JUN 30 11 50 AM '88

18. I hereby certify that the foregoing is true and correct

SIGNED *J.C. Williamson* TITLE Agent DATE 6-29-88

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE 7-13-88

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side