

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRI  
(Other instruction  
verse side)

Form approved.  
Budget Bureau No. 1004-0135  
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

NM-30886-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Yeso Hills Federal

9. WELL NO.

#1

10. FIELD AND POOL, OR WILDCAT

Wildcat Bone Spring

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec.18: T26S-R25E

12. COUNTY OR PARISH

Eddy

13. STATE

NM

1. OIL ☐ GAS ☒ OTHER ☐  
WELL WELL

2. NAME OF OPERATOR

Strata Production Company

3. ADDRESS OF OPERATOR

648 Petroleum Building, Roswell, NM 88201

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface

460'FSL & 1780'FEL

14. PERMIT NO.

API-30-015-26278

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3839'GL

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*


(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Strata Production Company intends to plug and abandon said well in the following manner:

- 1) TOH with 2 3/8" tubing and tubing anchor.
- 2) TIH with 5 1/2" CIBP and set at 4050' with 35' cement on top. This will cover Delaware perms 4098'-4107'.
- 3) TIH with 2 3/8" tubing to circ 9# gel/mud laden fluid from 4000' to surface.
- 4) Lay down tubing to a depth of 1265' and set 200' cement plug.
- 5) Set 50' cement plug at surface. Cut off wellhead and anchors and set dry hole marker.

NOTE: BLM will be notified in sufficient time to witness plugging procedure.



18. I hereby certify that the foregoing is true and correct

SIGNED

*Frank S. Moya*

Vice President of  
TITLE Field Operations

DATE 05/30/91

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

5/31/91

\*See Instructions on Reverse Side