

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or reenter an abandoned well. Use Form 3160-3 (APD) for such proposals.

RECEIVED

2004 MAR -2 AM 10:40

070 Farmington, NM

FORM APPROVED
OMB No. 1004-0135
Expires July 31, 1996

5. Lease Serial No.

14-20-603-321

6. If Indian, Allottee or Tribe Name

7. If Unit or CA/Agreement, Name and/or N

Central Bisti Unit

8. Well Name and No.

Central Bisti Unit #10

9. API Well No.

30-045-05543

10. Field and Pool, or Exploratory Area

Bisti Lower Gallup

11. County or Parish, State

San Juan County, New Mexico

SUBMIT IN TRIPLICATE - Other instructions on reverse side

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Elm Ridge Resources, Inc.

3a. Address

PO Box 189, Farmington, NM 87499

3b. Phone No. (include area code)

505-632-3476

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1980 FSL & 1880 FWL


Sec. 4 - T25N- R12W

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Acidize <input type="checkbox"/> Deepen <input type="checkbox"/> Production (Start/Resume) <input type="checkbox"/> Water Shut-Off
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Alter Casing <input type="checkbox"/> Fracture Treat <input type="checkbox"/> Reclamation <input type="checkbox"/> Well Integrity
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Casing Repair <input type="checkbox"/> New Construction <input type="checkbox"/> Recomplete <input type="checkbox"/> Other
	<input type="checkbox"/> Change Plans <input checked="" type="checkbox"/> Plug and Abandon <input type="checkbox"/> Temporarily Abandon
	<input type="checkbox"/> Convert to Injection <input type="checkbox"/> Plug Back <input type="checkbox"/> Water Disposal

13. Describe Proposed or Completed Operations (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recomple horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recomple in a new interval, a Form 3160-4 shall be filed once Testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.)

Elm Ridge Resources, Inc. plans to P & A the above referenced well. Please see attached.



14. I hereby certify that the foregoing is true and correct

Name (Printed/Typed)

Amy Mackey

Title

Production Technician

Signature

Amy Mackey

Date

February 27, 2004

THIS SPACE FOR FEDERAL OR STATE USE

Approved by

Original Signed: Stephen Mason

Title

Date

MAR 04 2004

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Office

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on reverse)

NMOCD

Elm Ridge Resources, Inc. plans to P & A the above referenced well as follows:

Remove Packer.

1. Plug 1 – T.I.H. set retainer @ 4655'
Pump 60 sks. Cement leave 25 sks on top of retainer.
2. Place 2 hole @ ~~2590'~~ ¹⁸⁷⁹
Set retainer @ ~~2490'~~ ¹⁸²⁹
Pump ~~20~~ sks. Sting out.
Place ~~15~~ sks. On top of retainer.
3. Shoot 2 hole @ ~~1900'~~ ^{1190'}
Set retainer @ ~~1890'~~ ¹⁰⁹⁰
Pump ~~20~~ sks cement sting out.
Place ~~15~~ sks. On top of retainer.
4. Shoot 2 hole @ ~~1090'~~ ^{832'}
Set retainer @ ~~1080'~~ ^{782'} attempt to circulate to surface.
Cement to surface.
5. Spot 100' plug from 355' to 255' in 5-½ casing.
6. Set ~~50'~~ ^{107'} plug @ surface.

Cut wellhead, install dry hole marker and remediate location.