


UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
OMB NO. 1004-0135
Expires January 31, 2004

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.

SUBMIT IN TRIPLICATE - Other instructions on reverse side



5. Lease Serial No.
Jicarilla Contract 12
6. If Indian, Allottee or Tribe Name
Jicarilla Apache
7. If Unit or CA/Agreement, Name and/or No.
Jicarilla P 10
8. Well Name and No.
Jicarilla P 10
9. API Well No.
30-039-05328
10. Field and Pool, or Exploratory Area
Ballard Pictured Cliffs
11. County or Parish, State
Rio Arriba NM

1. Type of Well
☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator
ENERGEN RESOURCES CORPORATION

3a. Address
2198 Bloomfield Highway, Farmington, NM 87401

3b. Phone No. (include area code)
505-325-6800

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
Unit C - 990' ENL, 1650' FWL, Sec. 28, T24N, R05W, N.M.P.M.

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION			
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Acidize	<input type="checkbox"/> Deepen	<input type="checkbox"/> Production (Start/Resume)	<input type="checkbox"/> Water Shut-Off
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Alter Casing	<input type="checkbox"/> Fracture Treat	<input type="checkbox"/> Reclamation	<input type="checkbox"/> Well Integrity
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> New Construction	<input type="checkbox"/> Recomplete	<input type="checkbox"/> Other
	<input type="checkbox"/> Change Plans	<input checked="" type="checkbox"/> Plug and Abandon	<input type="checkbox"/> Temporarily Abandon	
	<input type="checkbox"/> Convert to Injection	<input type="checkbox"/> Plug Back	<input type="checkbox"/> Water Disposal	

13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleat horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleat in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the final site is ready for final inspection.)

It is intended to plug and abandon this well as per the attached plugging procedure.

14. I hereby certify that the foregoing is true and correct
Name (Printed/Typed)
Vicki Donaghey

Title
Regulatory Analyst

Date
08/10/04

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Approved by
/s/ David R. Sitzler

Title
Division of Multi-Resources

Date
AUG 18 2004

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Office

Title 18 U.S.C. Section 1001, and Title 43 U.S.C. Section 1212, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

PLUG AND ABANDONMENT PROCEDURE

7/27/04

Jicarilla P #10

Pictured Cliffs

990' FNL & 1650' FWL, Section 28, T24N, R5W
San Juan County, New Mexico, API #30-039-05328

66586L

Note: All cement volumes use 100% excess outside pipe and 50' excess inside pipe. The stabilizing wellbore fluid will be 8.3 ppg, sufficient to balance all exposed formation pressures.
All cement will be ASTM Type III, mixed at 14.8 ppg with a 1.32 cf/sx yield.

1. Install and test location rig anchors. Prepare blow pit. Comply with all NMOCD, BLM, and Energen safety regulations. MOL and RU daylight pulling unit. Conduct safety meeting for all personnel on location. NU relief line and blow down well; kill with water as necessary. ND wellhead and NU BOP. Test BOP.
2. TOH and LD 1" tubing, total 2300'. PU and tally tubing workstring. Roundtrip 5-1/2" casing scraper or wireline gauge ring to 2205'.
3. Plug #1 (Pictured Cliffs perforations, Fruitland and Kirtland tops ~~2252~~ 1850'): TIH and set 5-1/2" CR ~~2250~~ Pressure test tubing to 1000#. Then load casing with water and circulate well clean. Pressure test casing to 800#. If casing does not test, then spot or tag subsequent plugs as appropriate. Mix 41 sxs Type III cement (54 cf) and spot a balanced plug inside casing above CR to isolate the Pictured Cliffs perforations to cover through the Kirtland top. TOH with tubing.
4. Plug #2 (Ojo Alamo top, 1790' - 1690'): Perforate 3 squeeze holes at 1790'. Attempt to establish rate into squeeze holes if the casing pressure tested. Set 5-1/2" cement retainer at 1740'. Establish rate into squeeze holes. Mix and pump 42 sxs Type III cement, squeeze 27 sxs outside the casing and leave 15 sxs inside casing. TOH and LD tubing.
Nacimiento top 1200 plug: 1250-1150
5. Plug #3 (8-5/8" Surface casing, 148' - Surface): Perforate 3 squeeze holes at 148'. Establish circulation out the bradenhead valve with water. Mix and pump approximately 50 sxs Type III cement down the 5-1/2" casing to circulate good cement out bradenhead valve. Shut well in and WOC.
6. ND BOP and cut off casing below surface casing flange. Install P&A marker with cement to comply with regulations. RD, move off location, cut off anchors and restore location.

7.

CONDITIONS OF APPROVAL FOR PERMANENT ABANDONMENT

Operator Energen Resources Corp Well Name Jic 12 P #10

1. Plugging operations authorized are subject to the "General Requirements for Permanent Abandonment of Wells on Federal Leases."
2. For wells on Federal leases, Alfonso Atencio with the Cuba Field Office is to be notified at least 24 hours (48 hours if possible) before the plugging operations commence. His phone number is (505) 289-3748, ext 218. Office hours are 7:45 a.m. to 4:30 p.m.

For wells on Jicarilla leases notify Bryce Hammond with the Jicarilla Apache Tribe at least 24 hours (48 hours if possible) before the plugging operations commence. His phone number is (505) 759-1783 ext. 28.

3. Blowout prevention equipment is required.
4. The following modifications to your plugging program are to be made :

None