UNITED STATES DEPARTMENT OF THE INTERTOR

	BUREAU OF LAND MA	NAGEMENT	
	Sundry Notices and R	eports on Wells	
_		5.	Lease Number NMSF-079250
GAS		6.	If Indian, All. or Tribe Name
. Name of Operator		7.	Unit Agreement Name
BURLINGTON		APR 2003	
RESOURCES	OIL & GAS COMPANY LP	100 Carrier 100 Mar.	San Juan 28-5 Unit Well Name & Number
. Address & Phone N		- 30	San Juan 28-5 U #291

3 PO Box 4289, Farmington, NM 87499 (505) 326 9700

4. Location of Well, Footage, Sec., T, R, M 1100'FNL, 940'FWL, Sec. 18, T-28-N, R-5-W, NMPM

 $\frac{}{2}$

API Well No. 30-039-22229

10. Field and Pool Tapacito PC/Blanco MV

11. County and State Rio Arriba Co, NM

-	Submission	Type of Action
v		-/5
^	Notice of Intent	Abandonment Change of Plans Recompletion New Construction
	Subsequent Report	Plugging Back Non-Routine Fracturing
	Final Abandonment	<pre> Casing Repair Water Shut off Altering Casing Conversion to Injection _X_ Other - Commingle</pre>

It is intended to commingle the subject well according to the attached procedure. A down hole commingle application will be submitted for approval.

CONDITIONS OF APPROVAL

Adhere to previously issued stipulations.

DHC 1998, 7-22-1998

070 Farmington, NM

14. L hereby certify that the foregoing is true and correct.	
Signed MW8) Title Regulatory Supervisor	Date 4/9/03
(This space for Federal or State Office use) APPROVED BY /S/JIM COURSE CONDITION OF APPROVAL, if any:	APR 2 2 2003

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

SAN JUAN 28-5 UNIT 29A Pictured Cliffs/Mesaverde 1100' FNL & 940' FWL

Unit D, Sec. 18, T28N, R05W

Latitude / Longitude: N36° 39.93 / W107° 24.372

AIN: 5341301/02

2/22/2003 Commingle Procedure

Summary/Recommendation:

San Juan 28-5 Unit 29A was drilled and completed as a PC/MV dual producer in 1980. Neither tubing string has been pulled since this well was originally completed. We will remove both strings and commingle the well with a single string of 2-3/8" tba.

- Comply with all NMOCD, BLM and Burlington safety and environmental regulations. Test rig anchors; utilize a 1. flow back tank instead of an earthen pit if possible. Notify BROG Regulatory (Peggy Cole 326-9727) and the appropriate regulatory agency prior to pumping any cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If verbal approval is obtained, document approval in DIMS.
- Slickline set tbg plug in MV tbg SN at 6129'; load MV tbg with 10bbls 2% KCl water. MOL and RU workover rig. Obtain and record all wellhead pressures. NU relief line. Blow well down and kill with 2% KCL water if 2. necessary. ND WH and NU BOP with stripping head. Test and record operation of BOP rams. Have wellhead and valves serviced as necessary. (A single-tubing donut and WH for 2-3/8" tubing will be needed.) Test secondary seal and replace/install as necessary.
- Pick up PC 1-1/4", 2.3#, J-55 tbg and RIH to the top of the liner (at 3861') to **gently** check for fill. If fill is present, TOOH w/ tubing and LD perforated orange peel joint. TIH w/ 1-1/4" tubing and circulate any fill off of the seal 3. assembly. TOOH and LD 1-1/4" tbg. Pick straight up on MV 2-3/8", 4.7#, J-55 tubing set at 6162' to release Baker Model G-22 seal assembly from Baker PBR set at 3882'. TOOH and stand back 2-3/8" tubing; LD seal Visually inspect tubing for scale/corrosion, and replace any bad joints. Notify Operations Engineer/Senior Rig Supervisor.
- PU 3-7/8" bit and bit sub on 2-3/8" tubing string and round trip to PBTD (5943'). CO to PBTD with air/mist using 4. a minimum mist rate of 12 bph. Alternate blow and flow periods at PBTD to check water and sand production rates. If scale is present, contact Operations Engineer/Senior Rig Supervisor to consider acid. TOOH and stand back tbg.
- TIH with an expendable check on bottom, seating nipple, one joint 2-3/8", 2' x 2-3/8" pup joint, then ½ of the 2-5. 3/8" tubing. Run a broach on sandline to ensure the tubing is clear. TIH with remaining 2-3/8" tubing and then broach this tubing. Replace bad joints as necessary.
- Land tubing at approximately 5920'. ND BOP and NU single-tubing hanger WH. Pump off expendable check. 6. Obtain final pitot gauge up the tubing. Connect to casing and circulate air to assure that the expendable check has pumped off. If well will not flow on its own, make swab run to seating nipple. During cleanout operations the reservoir may be charged with air. As a result of excess oxygen levels that may be in the reservoir and/or wellbore, contact the Lease Operator to determine oxygen levels prior to returning the well to production. RD and MOL. Return well to production.

Recommended:

Approved:

Approved

Drilling Manager

Mike Wardinsky

Office: 599-4045

Cell: 320-5113

Sundry Required:

3-31-03

Regulatory Approval

Foreman:

Ken Johnson Office: 326-9819

Cell: 320-2567 Pager: 324-7676

Lease Operator: Brent Elledge Specialist:

Garry Nelson

Cell: 320-2482 Pager: 326-8784 Cell: 320-2565 Pager: 326-8597

MHW/clc