Submit 3 Copies To Appropriate District Office	State of N				Form C-103	
District I 1625 N. French Dr., Hobbs, NM 88240	Energy, Minerals a	ind Natu	ral Resources	WELL API NO.	Revised March 25, 199	9
District II	OIL CONSERV.	ATION	DIVISION	30-045-	09937	
1301 W. Grand Avenue, Artesia, NM 87210 District III	1220 South			5. Indicate Type	of Lease	7
1000 Rio Brazos Rd., Aztec, NM 87410	Santa Fe,			STATE C		_
District IV 1220 S. St. Francis Dr., Santa Fe, NM 87505		, ,		6. State Oil & G	as Lease No.	
SUNDRY NOTICI (DO NOT USE THIS FORM FOR PROPOSA DIFFERENT RESERVOIR. USE "APPLICA" PROPOSALS.) 1. Type of Well: Oil Well Gas Well		EN OR PLU	JG BACK TO A	Holseshne	r Unit Agreement Name:	
2. Name of Operator	nceak d Enely			8. Well No. 23	 9	
1 3 Address of Operators	A .	•	 	9. Pool name or \		\dashv
4. Well Location	of OCD	1777				\dashv
	9/_feet from the _	N	line and	33/feet from	m theline	3
Section 2	Township 30)N∕ Ra	nge 16W	NMPM	County	
	10. Elevation (Show wi	hether DI	R, RKB, RT, GR, et			
11. Check Ap	propriate Box to Ind	icate Na	ature of Notice,	Report or Other	Data	
NOTICE OF INT	ENTION TO:			SÉQUENT RE	PORT OF:	
PERFORM REMEDIAL WORK	PLUG AND ABANDON	D 3 €	REMEDIAL WOR	≀к 🗆	ALTERING CASING	コ
TEMPORARILY ABANDON	CHANGE PLANS		COMMENCE DR	ILLING OPNS.	PLUG AND ABANDONMENT	
	MULTIPLE COMPLETION		CASING TEST A CEMENT JOB	ND 🗆		
OTHER:			OTHER:]	
 Describe proposed or completed of starting any proposed work). or recompilation. 						
See AttA	chment			100 S. A. S.	To the second se	
I hereby certify that the information a SIGNATURE CHARIE The	A .	ete to the l	•	dge and belief.	_DATE	-
Type or print name				Teler	ohone No.	
(This space for State use)					1 6 - m	M)O
APPPROVED BY Conditions of approval, if any:	The	TITLE_	FUTY OIL & GAS	INSPECTOR, DIST. 2	JUN STANKE	_

API WELL	Well Name	Well #	Operator Name	Typë	Stat	County	Sürf_Owner	UL	Sec	Twp	N/S	Rng	W/E	Feet	NS	Ft	EW	Order_No
1	HORSESHOE GALLUP UNIT		PLAYA MINERALS & ENERGY INC	Ο	A	San Juan	S	E	2	30	N	16	W	2191	Z	331	V	

,													
	വ	8 5/8	215	708			1 1/2	1728	850		2 3/8	1710	1567 1719
1	CO	0 3/0	213	103		1	4 1/2	1720	000	1	2 3/0	1119	1307-1710
									1	1			
-		<u> </u>	<u> </u>	<u> </u>					l i		1		

Procedure

MIRU, NUBOPE,

POOH Lay Down Rods & Tubing if present,

RIH with Gauge ring,

Pick up work string, Run Scrapper if required,

RIH Set CIBP /500 ', cap with 200 'cement .

Test casing.

POOH lay down tubing.

RU wire line RIH, perforate @ <u>265</u>' + - 50' under surface casing shoe or Mesa Verde base whichever is lower...

Establish Circulation; circulate cement to surface inside and outside casing

Cut off well head and install P&A marker

Cut off anchors 2' below ground

Clean and level location