

Submit 3 Copies To Appropriate District Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
1301 W. Grand Ave., Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
May 27, 2004

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-045-07485
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		7. Lease Name or Unit Agreement Name Jones A LS
1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/>		8. Well Number 4
2. Name of Operator BP America Production Company - Attn: Mary Corley		9. OGRID Number 000778
3. Address of Operator P.O. Box 3092 Houston, TX 77253		10. Pool name or Wildcat Blanco Mesaverde/Otero Chacra
4. Well Location Unit Letter <u>B</u> : <u>990</u> feet from the <u>North</u> line and <u>1830</u> feet from the <u>East</u> line Section <u>13</u> Township <u>28N</u> Range <u>08W</u> NMPM San Juan County		
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 6390' GR		
Pit or Below-grade Tank Application <input type="checkbox"/> or Closure <input type="checkbox"/>		
Pit type <u>Workover</u> Depth to Groundwater <u>>100'</u> Distance from nearest fresh water well <u><1000'</u> Distance from nearest surface water <u>>1000'</u>		
Pit Liner Thickness: <u>12</u> mil Below-Grade Tank: Volume _____ bbls; Construction Material _____		

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ P AND A ☐
CASING/CEMENT JOB ☐

OTHER: **Complete into Chacra & DHC w/Mesaverde**

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

BP America Production Company request permission to recomplete the subject well into the Otero Chacra Pool and commingle production Downhole with the existing Blanco Mesaverde as per the attached procedure. The Blanco Mesaverde (72319) and Otero Chacra (82329) Pools are Pre-Approved Pools for Downhole Commingling per NMOCD order R-11363. The working and overriding royalty interest owners in the proposed commingled pools are identical, therefore no additional notification is required. BLM has been notified via FORM 3160-5. Production is proposed to be allocated based on the subtraction method using the projected future decline for production from the Mesaverde. That production shall serve as a base for production subtracted from the total production for the commingled well. The balance of the production will be attributed to the Chacra. Attached is the future production decline estimates for the Mesaverde. Commingling Production Downhole in the subject well from the proposed Pools with not reduce the value of the total remaining production

Construct a lined workover pit per BP America - San Juan Basin Drilling/ Workover Pit Construction Plan issued date of 11/17/2004. Pit will be closed according to closure plan on file.

I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed or closed according to NMOCD guidelines ☐, a general permit ☐ or an (attached) alternative OCD-approved plan ☐.

SIGNATURE Mary Corley TITLE Sr. Regulatory Analyst DATE 03/08/2005
Type or print name Mary Corley E-mail address: corlevml@bp.com Telephone No. 281-366-4491

For State Use Only

APPROVED BY: [Signature] TITLE DEPUTY OIL & GAS INSPECTOR, DIST. 68 DATE MAR 14 2005
Conditions of Approval (if any):

Jones A LS 4 API #: 30-045-07485
Complete into the Chacra & DHC with the Mesaverde
February 28, 2005

Procedure:

1. Perform pre-rig site inspection. Check for: size of location, Gas Taps, other wells, other operators, running equipment, wetlands, wash (dikes req.), H₂S, barriers needed for equipment, Landowner issues, location of pits (buried lines in pits), Raptor nesting, critical location, check anchors. Check ID wellhead, if earth pit is required have One Call made 48 hours prior to digging.
2. Perform second site visit after lines are marked to ensure all lines clear marked pit locations. Planning and Scheduling to ready location for rig.
3. RU slickline unit or wireline unit. Pressure test lubricator and equipment. RIH and set **two** barriers (CIBP, tbg collar stop w/plug, or plug set in nipple) for isolation in tubing string.
4. Check and record tubing, casing, and bradenhead pressures. Ensure production casing has double casing valves installed. Double valve all casing strings.
5. MIRU workover rig. LO/TO all necessary equipment including but not limited to: meter run, Automation, Separators and water lines.
6. Blow down well. Kill with 2% KCL water ONLY if necessary.
7. Check all casing strings to ensure no pressure exist on any annulus. **The operations of removal of wellhead and installation of BOP's will be performed under a dispensation for one (1) barrier on the backside.**
8. Nipple down Wellhead. NU BOPs and diversion spool with 3" outlets and 3" pipe to the blow tank. Pressure test BOPs to 200 psi above BHP. Monitor flowing casing pressure with gauge (with casing flowing to blow tank) throughout workover.
9. Install stripping rubber, pull tubing hanger up above pipe rams, and shut pipe rams. Remove stripping rubber. Strip tubing hanger out of hole. Re-install stripping rubber.
10. TOH and LD 2-3/8" production tubing currently set at 5282'. Using approved "Under Balance Well Control Tripping Procedure".
11. TIH w/ scraper for 5-1/2". Check the distance between the top of the blind rams and the length of the bottom hole assembly that is being run. If the BHA is too long then the well has to be top killed and monitored prior to opening blind rams. RIH to PBTD at 5,320'. POOH.
12. Set bridge plug at 4,600'. Fill casing w/ 2%KCl and test to 2,500 psi w/ rig pumps.
13. Prepare for explosive operations. Follow Schlumberger Explosive SOP including radio silence, suspension of welding operations, and isolation of electrical devices from the work area. Perform Pre-job Safety Meeting to review JSA and procedures. Meeting should address the VDR (vehicle data recorder) System that Bp people have installed on their vehicles. They must be shut off at the 300 foot sign by hitting 00 and then the enter button, and then wait for about 5 minutes for the unit to turn off. When the green light goes out, call the control center at 326-9475. This number is on a pickup list in the Optimizer room and should be your first point of contact followed by the front desk then the weekend pager. Verify the unit is not transmitting. You then can drive to location and park,

but do not to exceed 10 Miles/hr. Note: 20 MPH will turn unit back on. If someone has On Star on their vehicle they cannot enter closer than 300 foot. On Star cannot be turned off. PLEASE take special caution. This is in conjunction with all cell phones, pagers, radios and any electronic devise that transmits a signal.

14. Perforate squeeze holes at 4,050' (previous CBL indicated TOC at 4,110).
15. Set cement retainer at 4,000'.
16. Sting into retainer. Circulate cement down tubing and up 5-1/2" by 7-5/8" annulus.
17. Sting out of retainer and circulate cement off of top of retainer. POOH and WOC.
18. RU E-line and run CBL from retainer to 2500' to confirm TOC is above Chacra.
19. RIH with 3-1/8" casing guns w/lubricator. Perforate Chacra formation w/ 4 SPF.
20. NU Frac isolation equipment. Install and monitor production casing and treating pressure during entire job in frac van via pressure transducers on production casing and treating line. Spearhead 500 gal 15% HCL, establish injection rate, and proceed with fracture stimulation according to Schlumberger schedule. Maintain surface pressures , 3000 psi during frac job. Flush frac with foam. Fill out GWSI scorecard.
21. Flowback frac immediately. Flow well through choke manifold on 1/4", 1/2" and 3/4" chokes increasing drawdown until well dies or stabilizes. This is to aid in reducing sand flowback. Recommend 8 hours of flow for each choke size.
22. Rig up air package/unit, pressure test all lines (Testing procedure to be supplied from air company), TIH with tubing and bit for 5-1/2" casing. Cleanout fill to top of BP set at 4,600'. **Perform well test on Chacra for regulatory and document well test in DIMS.**
23. Cleanout fill, cement retainer, & BP set at 4600'. Cleanout to PBTD at 5,320'. Blow well dry.
24. Rabbit tubing and RIH with 2-3/8" production tubing (with muleshoe, F-nipple with plug, 4 ft pup, X-nipple with plug).
25. Land 2-3/8" production tubing at +/-5,285'. Lock down hanger.
26. Pressure test tubing to 500 psi with air unit, make sure tubing spool valves are open. Care should be taken during pressure testing of the tubing due to potential problem caused if tubing parts close to surface or above the hanger. Check all casing string for pressure. **The operations of removal of wellhead and installation of BOP's will be performed under a dispensation for one (1) barrier on the backside.**
27. ND BOP's. NU Wellhead. During Master valve placement ensure the top of hanger has spacer nipple in place to bottom of bonnet flange so plunger equipment will not hang up through tree. Pressure test Wellhead.
28. RU WL unit. Run gauge ring for 2-3/8" tubing. Pull plugs and set tubing stop for plunger. Communicate plunger equipment status to IC room personnel.
29. RD slickline unit.
30. Test well for air. Return well to production and downhole co-mingle Chacra and Mesaverde.

Jones A LS 4

Sec 13, T28N, R8W

API #: 3004507485

GL: 6390'

History:

- Drilled and completed in 1956
- Added Menefee in 03

TOC @ surf (circ)

10 3/4" 32.75#, P.E., S.W. @ 177'

7 5/8" TOC @ 1800'
(Temp. survey)

7 5/8" 26.4#, 8RD, J-55 @ 3145'
cemented w/ 125 sx reg cmt + 125 sx pozmix

5 1/2" TOC @ 3725' (TS)

5 1/2" TOC @ 4110' (CBL)

MV perforations

4656' - 4668', 4 spf, frac'd w/ 55,000# sand

4680' - 4690', 4 spf, frac'd w/ 55,000# sand

4744' - 4756', 4 spf, frac'd w/ 55,000# sand

4856'-5140', 2 spf, frac'd w/ 75,000# sand

5221' - 5233', 4 spf, frac'd w/ 55,000# sand

5262' - 5275', 4 spf, frac'd w/ 55,000# sand

5296' - 5313', 4 spf, frac'd w/ 55,000# sand

Tubing: 2-3/8" 4.7#, J55 @ 5282'

5 1/2" 15.5#, 8RD, J-55 Csg @ 5360'

PBTD: 5320'

cemented w/ 125sx reg cmt + 125sx pozmix

TD: 5365'

updated: 02/1/04 CFR

District I

1625 N. French Dr., Hobbs, NM 88240

District II

811 South First, Artesia, NM 88210

District III

1000 Rio Brazos Rd., Aztec, NM 87410

District IV

2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico
Energy, Minerals & Natural Resources Department**OIL CONSERVATION DIVISION**

2040 South Pacheco

Santa Fe, NM 87505

Form C-102

Revised August 15, 2000

Submit to Appropriate District Office

State Lease - 4 Copies

Fee Lease - 3 Copies

AMENDED REPORT

WELL LOCATION AND ACREAGE DEDICATION PLAT

¹ API Number 30-045-07485	² Pool Code 82329	³ Pool Name Otero Chacra
⁴ Property Code 000759	⁵ Property Name Jones A LS	⁶ Well Number 4
⁷ OGRID No. 000778	⁸ Operator Name BP America Production Company	⁹ Elevation 6310' GR

¹⁰ Surface Location

UL or lot no. B	Section 13	Township 28N	Range 08W	Lot Idn	Feet from 990	North/South North	Feet from 1830	East/West East	County San Juan
---------------------------	----------------------	------------------------	---------------------	---------	-------------------------	-----------------------------	--------------------------	--------------------------	---------------------------

¹¹ Bottom Hole Location If Different From Surface

UL or lot no.	Section	Township	Range	Lot Idn	Feet from	North/South	Feet	East/West	County
¹² Dedicated Acres 160	¹³ Joint or Infill	¹⁴ Consolidation Code	¹⁵ Order No.						

NO ALLOWABLE WILL BE ASSIGNED TO THIS COMPLETION UNTIL ALL INTERESTS HAVE BEEN CONSOLIDATED OR A
NON-STANDARD UNIT HAS BEEN APPROVED BY THE DIVISION

	¹⁷ OPERATOR CERTIFICATION	
	I hereby certify that the information contained herein is true and complete to the best of my knowledge and belief.	
	Signature Mary Corley Printed Name Sr. Regulatory Analyst Title 3/8/2005 Date	
	¹⁸ SURVEYOR CERTIFICATION	
	I hereby certify that the well location shown on this plat was plotted from field notes of actual surveys made by me or under my supervision, and that the same is true and correct to the best of my belief.	
	12/23/1956 Date of Survey Signature and Seal of Professional Surveyor: C O Walker Certificate Number	

Jones A LS 4 Future Production Decline Estimate **Mesaverde Daily Rates**

3/8/2005

Month	Gas Volume
Jan-2004	154
Feb-2004	128
Mar-2004	141
Apr-2004	135
May-2004	129
Jun-2004	93
Jul-2004	123
Aug-2004	120
Sep-2004	120
Oct-2004	126
Nov-2004	123
Dec-2004	125
Jan-2005	106
Feb-2005	106
Mar-2005	105
Apr-2005	105
May-2005	104
Jun-2005	104
Jul-2005	104
Aug-2005	103
Sep-2005	103
Oct-2005	102
Nov-2005	102
Dec-2005	102
Jan-2006	101
Feb-2006	101
Mar-2006	100
Apr-2006	100
May-2006	100
Jun-2006	99
Jul-2006	99
Aug-2006	99
Sep-2006	98
Oct-2006	98
Nov-2006	97
Dec-2006	97

$\ln(Q_f/Q_i) = -dt$
 $Q_f = 125$
 $Q_i = 129$
 $rate = 125$
 $time = 8$
 $dt = -0.031498667$
 $decline = -0.003937333$

Month	Gas Volume
Jan-2007	97
Feb-2007	96
Mar-2007	96
Apr-2007	95
May-2007	95
Jun-2007	95
Jul-2007	94
Aug-2007	94
Sep-2007	94
Oct-2007	93
Nov-2007	93
Dec-2007	92
Jan-2008	92
Feb-2008	92
Mar-2008	91
Apr-2008	91
May-2008	91
Jul-2008	90
Aug-2008	90
Sep-2008	90
Oct-2008	89
Nov-2008	89
Dec-2008	89
Jan-2009	88
Feb-2009	88
Mar-2009	88
Apr-2009	87
May-2009	87
Jun-2009	86
Jul-2009	86
Aug-2009	86
Sep-2009	85
Oct-2009	85
Nov-2009	85
Dec-2009	84
Jan-2010	84

Month	Gas Volume
Feb-2010	84
Mar-2010	83
Apr-2010	83
May-2010	83
Jun-2010	83
Jul-2010	82
Aug-2010	82
Sep-2010	82
Oct-2010	81
Nov-2010	81
Dec-2010	81
Jan-2011	80
Feb-2011	80
Mar-2011	80
Apr-2011	79
May-2011	79
Jun-2011	79
Jul-2011	78
Aug-2011	78
Sep-2011	78
Oct-2011	77
Nov-2011	77
Dec-2011	77
Jan-2012	77
Feb-2012	76
Mar-2012	76
Apr-2012	76
May-2012	75
Jun-2012	75
Jul-2012	75
Aug-2012	74
Sep-2012	74
Oct-2012	74
Nov-2012	74
Dec-2012	73
Jan-2013	73

Jones A LS 4 Future Production Decline Estimate **Mesaverde Daily Rates**

Month	Gas Volume
Feb-2013	73
Mar-2013	72
Apr-2013	72
May-2013	72
Jun-2013	72
Jul-2013	71
Aug-2013	71
Sep-2013	71
Oct-2013	70
Nov-2013	70
Dec-2013	70
Jan-2014	70
Feb-2014	69
Mar-2014	69
Apr-2014	69
May-2014	69
Jun-2014	68
Jul-2014	68
Aug-2014	68
Sep-2014	67
Oct-2014	67
Nov-2014	67
Dec-2014	67
Jan-2015	66
Feb-2015	66
Mar-2015	66
Apr-2015	66
May-2015	65
Jun-2015	65
Jul-2015	65
Aug-2015	65
Sep-2015	64
Oct-2015	64
Nov-2015	64
Dec-2015	64
Jan-2016	63

Month	Gas Volume
Feb-2016	63
Mar-2016	63
Apr-2016	63
May-2016	62
Jun-2016	62
Jul-2016	62
Aug-2016	62
Sep-2016	61
Oct-2016	61
Nov-2016	61
Dec-2016	61
Jan-2017	60
Feb-2017	60
Mar-2017	60
Apr-2017	60
May-2017	60
Jun-2017	59
Jul-2017	59
Aug-2017	59
Sep-2017	59
Oct-2017	58
Nov-2017	58
Dec-2017	58
Jan-2018	58
Feb-2018	57
Mar-2018	57
Apr-2018	57
May-2018	57
Jun-2018	57
Jul-2018	56
Aug-2018	56
Sep-2018	56
Oct-2018	56
Nov-2018	55
Dec-2018	55
Jan-2019	55