

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

FORM APPROVED  
OMB No. 1004-0135  
Expires November 30, 2000

**SUNDRY NOTICES AND REPORTS ON WELLS**  
*Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.*

**SUBMIT IN TRIPLICATE - Other instructions on reverse side**

1. Type of Well <input type="checkbox"/> Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other		5. Lease Serial No. Jic Contract 34
2. Name of Operator Four Star Oil and Gas Company		6. If Indian, Allottee or Tribe Name Jicarilla Apache
3a. Address 11111 S. Wilcrest Houston, Tx. 77099	3b. Phone No. (include area code) (281) 561-4991	7. If Unit or CA/Agreement, Name and/or No.
4. Location of Well (Footage, Sec., T., R., M., or Survey Description) 1650' from the South line & 1750' from the East line Sec. 28 T25N, R5W NMPM		8. Well Name and No. Jicarilla C #5
		9. API Well No. 30-039-05815
		10. Field and Pool, or Exploratory Area Blanco-P.C. South
		11. County or Parish, State San Juan, New Mexico

**12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA**

TYPE OF SUBMISSION	TYPE OF ACTION			
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Acidize	<input type="checkbox"/> Deepen	<input type="checkbox"/> Production (Start/Resume)	<input type="checkbox"/> Water Shut-Off
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Alter Casing	<input type="checkbox"/> Fracture Treat	<input type="checkbox"/> Reclamation	<input type="checkbox"/> Well Integrity
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> New Construction	<input type="checkbox"/> Recomplete	<input type="checkbox"/> Other
	<input type="checkbox"/> Change Plans	<input checked="" type="checkbox"/> Plug and Abandon	<input type="checkbox"/> Temporarily Abandon	
	<input type="checkbox"/> Convert to Injection	<input type="checkbox"/> Plug Back	<input type="checkbox"/> Water Disposal	

13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleat horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleat in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.)

Four Star Oil & Gas Company intends to plug & abandon the subject well according to the attached procedure.

2005 MAR 14 PM 9:56  
RECEIVED  
OTO FARMINGTON LHM

14. I hereby certify that the foregoing is true and correct Name (Printed/Typed) Kenneth W. Jackson		Title Regulatory Specialist
Signature <i>Kenneth W. Jackson</i>		Date 3/10/05

**THIS SPACE FOR FEDERAL OR STATE OFFICE USE**

Approved by <b>Original Signed: Stephen Mason</b>	Title	Date <b>APR 20 2005</b>
Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.	Office	

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

AMOC

## PLUG AND ABANDONMENT PROCEDURE

JICARILLA C #5  
PC  
SEC. 26, T25N, R5W  
RIO ARriba COUNTY, NM

NOTE: ALL CEMENT VOLUMES USE 100% EXCESS OUTSIDE PIPE AND 50' EXCESS INSIDE PIPE. THE STABILIZING WELLBORE FLUID WILL BE 8.34 PPG, SUFFICIENT TO BALANCE ALL EXPOSED FORMATION PRESSURES.

1. INSTALL AND TEST RIG ANCHORS. PREPARE BLOW PIT. COMPLY WITH ALL BLM, AND TEXACO REGULATIONS.

2. MOL AND RU. CONDUCT SAFETY MEETING WITH ALL PERSONNEL ON LOCATION. NU RELIEF LINE. BLOW DOWN WELL, AND KILL WITH H2O IF NECESSARY. ND WELLHEAD AND NU BOP

3. TOOK W/2 3/8" TUBING. RIH W/GAUGE RING TO 2630'. SET CIBP @ 2620'.

4. PU 2 3/8" TUBING & TAG CIBP @ 2620'. LOAD HOLE & PRESS TEST TO 500 PSI.

5. PLUG #1 (PC FRUITLAND) 2620'-<sup>2298'</sup>2520'. 17 SX. POOH. PERF @ 1460'. SET CIBP @ 1410'.

6. PLUG #2 (KIRTLAND) 1460'-<sup>Ojo Alamo 2334' 2088'</sup>1380'. 48 SX. (12 SX ABOVE RET & 36 SX BELOW) POOH. PERF @ 261'. ESTABLISH CIRC TO SURFACE.

7. PLUG #3 (261'-SURFACE) MIX AND PUMP CEMENT UNTIL GOOD RETURNS ARE EVIDENT (APPROXIMATELY 140 SX)  
*Nueces plug 797'-697' inside outside 5 1/2" casing*

ND BOP & RD FLOOR. DIG CELLAR AND CUT OFF WELLHEAD. TOP OFF CASING STRINGS AS NEEDED. RD AND MOL. CUT OFF ANCHORS AND INSTALL DRY HOLE MARKER.

3E → 2E

PROPOSED WELL BORE DIAGRAM  
JICARILLA C #5

