

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

FORM APPROVED  
OMB No. 1004-0137  
Expires: July 31, 2010

**SUNDRY NOTICES AND REPORTS ON WELLS**  
*Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.*

5. Lease Serial No. **SF-078738**

6. If Indian, Allottee or Tribe Name

*SUBMIT IN TRIPLICATE - Other instructions on page 2.*

1. Type of Well  
 Oil Well  Gas Well  Other

7. If Unit of CA/Agreement, Name and/or No. **San Juan 30-5 Unit**

2. Name of Operator **ConocoPhillips Company**

8. Well Name and No. **San Juan 30-5 Unit 247R**

3a. Address **PO Box 4289, Farmington, NM 87499**

3b. Phone No. (include area code) **(505) 326-9700**

9. API Well No. **30-039-29233**

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)  
**Surface UL A (NENE), 710' FNL & 925' FEL, Sec. 26, T30N, R5W**

10. Field and Pool or Exploratory Area **Basin FC**

11. Country or Parish, State **Rio Arriba New Mexico**


12. CHECK THE APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION		
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Acidize	<input type="checkbox"/> Deepen	<input type="checkbox"/> Production (Start/Resume)
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Alter Casing	<input type="checkbox"/> Fracture Treat	<input type="checkbox"/> Reclamation
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> New Construction	<input type="checkbox"/> Recomplete
	<input type="checkbox"/> Change Plans	<input checked="" type="checkbox"/> Plug and Abandon	<input type="checkbox"/> Temporarily Abandon
	<input type="checkbox"/> Convert to Injection	<input type="checkbox"/> Plug Back	<input type="checkbox"/> Water Disposal
			<input type="checkbox"/> Water Shut-Off
			<input type="checkbox"/> Well Integrity
			<input type="checkbox"/> Other

13. Describe Proposed or Completed Operation; Clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleat horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports must be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleat in a new interval, a Form 3160-4 must be filed once Testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has determined that the site is ready for final inspection.)

ConocoPhillips requests permission to P&A the subject well bore per the attached procedure, current & proposed well bore schematics. A closed loop system Will be utilized for this P&A. No Re-Vegetation plan is attached as this well is on Forest surface.

BLM'S APPROVAL OR ACCEPTANCE OF THIS ACTION DOES NOT RELIEVE THE LESSEE AND OPERATOR FROM OBTAINING ANY OTHER AUTHORIZATION REQUIRED FOR OPERATIONS ON FEDERAL AND INDIAN LANDS



SEE ATTACHED FOR CONDITIONS OF APPROVAL

14. I hereby certify that the foregoing is true and correct. Name (Printed/Typed)

**Kenny Davis**

Title **Staff Regulatory Technician**

Signature *[Handwritten Signature]*

Date **1/6/2015**

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Approved by **Troy Salvors** Title **PE** Date **1/21/2015**

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon. Office **FFO**

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*Handwritten initials*

*Handwritten initials*

**ConocoPhillips**  
**SAN JUAN 30-5 UNIT 247R**  
**Expense - P&A**

Lat 36° 47' 20" N

Long 107° 19' 13.001" W

**PROCEDURE**

**This project requires the use of an A-Plus steel tank to handle waste fluids circulated from the well and cement wash up.**

1. Hold pre-job safety meeting. Comply with all NMOCD, BLM, and COPC safety and environmental regulations. Test rig anchors prior to moving in rig.
2. MIRU workover rig. Check casing, tubing, and bradenhead pressures and record them in Wellview. **If there is pressure on the BH, contact the Wells Engineer.**
3. Remove existing piping on casing valve. RU blow lines from casing valves and begin blowing down casing pressure. Kill well as necessary. Ensure well is dead or on a vacuum.
4. TOOH w/ rod string and LD (per pertinent data sheet).  

<b>Size:</b>	3/4"	<b>Set Depth:</b>	3,846	ft
--------------	------	-------------------	-------	----
5. ND wellhead and NU BOPE. Pressure and function test BOP to 250 psi low and 1000 psi over SICP high to a maximum of 2000 psi held and charted for 10 minutes as per COP Well Control Manual. PU and remove tubing hanger
6. TOOH with tubing (per pertinent data sheet).  

<b>Tubing size:</b>	2-3/8"	4.7# J-55 EUE	<b>Set Depth:</b>	3865	ftKB	<b>KB:</b>	11	ft
---------------------	--------	---------------	-------------------	------	------	------------	----	----
7. PU 6-1/4" bit and watermelon mill and round trip above liner top @ 3722'.
8. PU 7" CR on tubing, and set @ 3672'. Pressure test tubing to 1000 psi. Sting out of CR. Load hole, and pressure test casing to 800 psi. *If casing does not test, then spot or tag subsequent plugs as appropriate.* POOH w/ tubing.
9. RU wireline and run CBL with 500 psi on casing from CR to surface to identify TOC. *Adjust plugs as necessary for new TOC.*

**All cement volumes use 100% excess outside pipe and 50' excess inside pipe. The stabilizing wellbore fluid will be 8.3 ppg, sufficient to balance all exposed formation pressures. All cement will be ASTM Class B mixed at 15.6 ppg with a 1.18 cf/sk yield.**

**10. Plug 1 (Fruitland, Kirtland and Ojo Alamo, 3144-3672', 112 Sacks Class B Cement)**

TIH with tubing to CR @ 3672'. Mix 112 sx Class B cement and spot a balanced plug inside the casing to cover the Fruitland, Kirtland, and Ojo Alamo tops. PUH.

*See COA*

**11. Plug 2 (Nacimiento, 1820-1920', 29 Sacks Class B Cement)**

Mix 29 sx Class B cement and spot a balanced plug inside the casing to cover the Nacimiento top. PUH.

**12. Plug 3 (Surface, 0-185', 46 Sacks Class B Cement)**


Connect the pump line to the bradenhead valve and attempt to pressure test the BH annulus to 300 psi. Note the volume to load. If the BH annulus holds pressure, then establish circulation out casing valve with water. Mix 46 sx Class B cement and spot balanced plug inside casing from 185' to surface, circulating good cement out casing valve. TOOH and LD tubing. SI well and WOC. If the BH annulus does not test, then perforate at the appropriate depth and attempt to circulate cement to surface, filling the casing and the BH annulus to surface. Shut well in and WOC.

13. Nipple down BOP and cut off casing below the casing flange. Install P&A marker with cement to comply with regulations. Rig down, move off location, cut off anchors, and restore location.

Well Name: **SAN JUAN 30-5 UNIT #247R**


API Well No. 3003929233	Surface Leg ID/Location 028-030N-005W-A	Field Name BASIN FRUITLAND COAL	License No.	State Province NEW MEXICO	Well Configuration Type VERTICAL
Ground Elevation (ft) 7,130.00	Original KBWT Elevation (ft) 7,141.00	CS-Ground Distance (ft) 11.00	CS-Casing Flange Distance (ft)	CS-Tubing Hanger Distance (ft) 7,141.00	

**VERTICAL - Original Hole, 11/13/2014 7:37:37 AM**



District CENTRAL	Field Name BASIN FRUITLAND COAL	API / UWI 3003929233	County RIO ARRIBA	State/Province NEW MEXICO
Original Spud Date 5/11/2007	Surface Legal Location 026-030N-005W-A	East/West Distance (ft) 925.00	East/West Reference FEL	North/South Distance (ft) 710.00
North/South Reference FNL				

#### VERTICAL - Original Hole, 1/1/2020 1:15:00 AM



UNITED STATES DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT  
FARMINGTON DISTRICT OFFICE  
6251 COLLEGE BLVD.  
FARMINGTON, NEW MEXICO 87402

Attachment to notice of  
Intention to Abandon:

Re: Permanent Abandonment  
Well: San Juan 30-5 Unit #247R

CONDITIONS OF APPROVAL

1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal and Indian Lease."
2. Farmington Office is to be notified at least 24 hours before the plugging operations commence (505) 564-7750.
3. The following modifications to your plugging program are to be made:
  - a) Set plug #2 (2076-1976) ft. to cover the Nacimiento top.

Operator will run a CBL to verify cement top. Submit the electronic copy of the log for verification to the following addresses: [tsalyers@blm.gov](mailto:tsalyers@blm.gov) [Brandon.Powell@state.nm.us](mailto:Brandon.Powell@state.nm.us)

You are also required to place cement excesses per 4.2 and 4.4 of the attached General Requirements.

Office Hours: 7:45 a.m. to 4:30 p.m.