Form 3160-5 (June 2015)

## UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED OMB NO. 1004-0137 Expires: January 31, 2018

5.	Lease Serial No.
	NMNM25857

SUNDRY NOTICES AND REPORTS ON WELLS	
Do not use this form for proposals to drill or to re-enter an	
abandoned well. Use form 3160-3 (APD) for such proposals	

SONDICT	NOTICES AND INEL OF	CIO CIV VVI	LLO		11111111120001		
Do not use the abandoned we	6. If Indian, Allottee or Tribe Name						
SUBMIT IN	7. If Unit or CA/Agreement, Name and/or No.						
Type of Well     Oil Well	8. Well Name and No. HOOVER 2						
Name of Operator HILCORP ENERGY COMPAN	ALKER		9. API Well No. 30-045-31220-00-S1				
3a. Address 1111 TRAVIS STREET HOUSTON, TX 77002		(include area code) 4-5122		10. Field and Pool or Exploratory Area TWIN MOUNDS FRUITLAND SAND PO			
4. Location of Well (Footage, Sec., T	., R., M., or Survey Description)			11. County or Parish, State			
Sec 21 T30N R14W NENE 80 36.804659 N Lat, 108.308759				SAN JUAN COUNTY, NM			
12. CHECK THE AF	PPROPRIATE BOX(ES)	TO INDICA	TE NATURE OI	F NOTICE,	REPORT, OR OTH	ER I	DATA
TYPE OF SUBMISSION		ACTION					
Notice of Intent   ■ Notice of Intent	☐ Acidize	☐ Deepen		☐ Product	ion (Start/Resume)		Water Shut-Off
	☐ Alter Casing	☐ Hyd	raulic Fracturing	☐ Reclam	ation		Well Integrity
□ Subsequent Report BP	□ Casing Repair	□ New	Construction	☐ Recomp	olete		Other
☐ Final Abandonment Notice	☐ Change Plans	☐ Plug	and Abandon	▼ Tempor	rarily Abandon		
	☐ Convert to Injection	☐ Plug Back		☐ Water I	Disposal		
following completion of the involved testing has been completed. Final Al determined that the site is ready for f Hilcorp Energy Company requ to return the well to production wellbore schematic.	pandonment Notices must be file inal inspection.	d only after all	n the subject we	ing reclamatio	n, have been completed a	nd the	operator has
			The strong	NMO	DD		
		SEP 05	0 5 2019				
	operations	DI	DISTRICT III				
14. I hereby certify that the foregoing is  Co  Name (Printed/Typed) AMANDA	Electronic Submission #4 For HILCORP EN mmitted to AFMSS for proc	IERGY COMP	ANY, sent to the HN HOFFMAN on	Farmington 09/03/2019 (			
Time Types Time Types	VVICENCE	OI LIVY	HONO REC	JOE TOTT TEST			
Signature (Electronic S	Submission)		Date 08/12/20	019			
	THIS SPACE FO	R FEDERA	L OR STATE	OFFICE U	SE		
_Approved_By_JQHN_HOFFMAN_	TitlePETROLE	UM ENGINI	EER		Date 09/03/2019		
Conditions of approval, if any, are attache certify that the applicant holds legal or equ which would entitle the applicant to condu	Office Farming	ton					
Title 18 U.S.C. Section 1001 and Title 43				willfully to ma	ake to any department or a	agency	of the United

(Instructions on page 2) \*\* BLM REVISED \*\* BLM REVISED \*\* BLM REVISED \*\* BLM REVISED \*\*





## Hilcorp Energy Company HOOVER 2

Temporarity Abandon API #: 3004531220

## PROCEDURE

- 1. Hold a pre-job safety meeting prior to beginning all operations or during a change in operational scope or initiation of SIMOPs. Properly document all operations via the JSA process. Insure that all personnel onsight abide by HEC safety protocol, including PPE, housekeeping, and procedures. Verify cathodic protection is off and wellhead instrumentation is properly disconnected from wellhead. Comply with all NMOCD, BLM, and HEC safety and environmental regulations. Verify there is no H2S present prior to beginning operations. If H2S is present, take the necessary actions to insure that the operation is safe prior to beginning operations. Observe and record pressures across all strings daily, prior to beginning operations. Notify NMOCD and BLM 24 hours in advance of beginning operations
- 2. RU slickline. RIH and clear tbg. Attempt to fish any obstructions or set a 3-slip stop in the tbg.
- 3. MIRU service rig and associated equipment, ND casing risers
- 4. ND tree and NU BOPs. Pressure and function test BOPs to 150/1500 psi.
- 5. PU on tbg, release hanger, scan and visually inspect tbg and POOH
- 6. PU junk mill and RIH to 1250', POOH LD junk mill
- 7. RIH w/ CBIP on tbg and set at 1200', PT CIBP and casing to 600 psi, POOH w/ setting tool.
- 8. RBIH w/ 250' of tbg to use as a kill string. NDNU tree verify tree and wellhead are equipped with functional pressure gauges. RDMO
- 9. Contact BLM and NMOCD to schedule witnessed MIT. PT csg to 600 psi.

