

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

FORM APPROVED  
OMB No. 1004-0135  
Expires November 30, 2000

RECEIVED

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to re-enter an  
Abandoned well. Use Form 3160-3 (APD) for such proposals.

5. Lease Serial No.

SF - 079938

6. If Indian, Allottee or tribe Name

7. If Unit or CA/Agreement, Name and/or No.

**SUBMIT IN TRIPLICATE - Other instructions on reverse side**

1. Type of Well

☐ Oil Well

☒ Gas Well

☐ Other

8. Well Name and No.

Jones A 1M

2. Name of Operator

BP America Production Company Attn: Mary Corley

9. API Well No.

30-045-31720

3a. Address

P.O. Box 3092 Houston, TX 77253

3b. Phone No. (include area code)

281-366-4491

10. Field and Pool, or Exploratory Area

Basin Dakota/Blanco Mesaverde

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1940' FNL & 1640' FWL Sec. 35 T29N, R08W

11. County or Parish, State

San Juan County, New Mexico

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OR NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

TYPE OF ACTION

☐ Acidize

☐ Deepen

☐ Production (Start/Resume)

☐ Water shut-Off

☐ Alter Casing

☐ Fracture Treat

☐ Reclamation

☐ Well Integrity

☐ Casing Repair

☐ New Construction

☐ Recomplete

☐ Other Cement SQZ

☐ Change Plans

☐ Plug and Abandon

☐ Water Disposal

☐ Convert to Injection

☐ Plug Back

13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleat horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleat in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.

Per conversation on September 16, 2003, with Jim Lovato please find attached recommended procedure to repair the cement job for the subject well.

14. I hereby certify that the foregoing is true and correct  
Name (Printed/typed)

Mary Corley

Title Senior Regulatory Analyst

Signature

*Mary Corley*

Date 09/16/2003

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

ACCEPTED FOR RECORD

Approved by

Title

Date

SEP 23 2003

Conditions of approval, if any, are attached. Approval of this notice does not warrant or Certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Office

FARMINGTON FIELD OFFICE

*OK*

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

NMOCD

## **Jones A 1M**

The CBL\_VDL run with pressure (1000 psi) showed free pipe from 6000 ft to surface. We recommend to shot (4 to 6 holes of 0.32") at 5950 ft, to communicate the casing with the annular and proceed as per the following program to repair the well:

1. RIH with a RBP and set it at 6150 ft.
2. Drop 4 sks of 20/40 sand on top of RBP.
3. Perforate at 5950 ft with 4-6 spf
4. RIH with a 4 ½" cement retainer and set it at 5850 ft.
5. RIH with 2 3/8" tubing and fill the casing with water, while circulating at low rate (1-2 bpm) sting into the retainer and test if able to circulate behind the casing. Circulate bottoms up via 7"x 4 ½" annular.
  - a. If circulation is possible then;
    - i. Stop pumps and unsting.
    - ii. Prepare lines to proceed with the cement job.
    - iii. Pump 5 bbls of water while stinging into the retainer.
    - iv. Pump 20 bbls of gelled water + CemNET (1-2 #/bbl).
    - v. Pump 70 bbls of LiteCRETE 9.5 ppg. (156 sks based on 6 ¼"OH + 30% excess and a column of 2950 ft).
    - vi. Displace the pipe capacity.
    - vii. Unsting and circulate bottoms up.
    - viii. Wait on cement 24 hrs and then proceed with the completion procedure.
  - b. If circulation is not possible communicate with BLM for further instructions.