| Office | State of New Mexico | | | Form C-103 | | | | |
|--|--|---------------------------|---------|---|------------|-------------|---|--|
| District 1 | Energy, Minerals and Natural Resources | | | Revised March 25, 1999 | | | | |
| 1625 N. French Dr., Hobbs, NM 88240 District II | | | | WELL API NO. 30-045-23119 | | | | |
| 1301 W. Grand Ave., Artesia, NM 88210 OIL CONSERVATION DIVISION | | | | 5. Indicate Type of Lease | | | | |
| District III 1000 Rio Brazos Rd., Aztec, NM 87410 Santa Fe, NM 87505 | | | | STATE FEE S | | | | |
| District IV 1220 S. St. Francis Dr., Santa Fe, NM | | | 6. | 6. State Oil & Gas Lease No. | | | | |
| 87505 | | | | | XX *. A | | - | |
| SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A | | | 7. | 7. Lease Name or Unit Agreement Name: Ward A | | | | |
| DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH | | | | | | | | |
| PROPOSALS.) 1. Type of Well: | | | | | | | | |
| Oil Well Gas Well Other | | | | | | | | |
| 2. Name of Operator Four Star Oil and Gos Company | | | | 8. Well No. #1 | | | | |
| Four Star Oil and Gas Company 3. Address of Operator | | | | 9. Pool name or Wildcat | | | | |
| P.O. Box 1289 Farmington, New Mexico 87499-1289 | | | | Otero Charca | | | | |
| 4. Well Location | | | | | | | | |
| Unit Letter L: 1710 feet from the | South | line and | 1180 | feet 1 | from the | West | line | |
| | | | | | _ | | | |
| | 29N | Range 11W | | NMPM | San Ju | an C | County | |
| 10. Elevation (Show whether DR, RKB, RT, GR, etc.) 5579 GR | | | | | | | | |
| 11. Check Appropriate Box to Ind | licate Na | ture of Notice | e, Rep | ort or Othe | er Data | | *************************************** | |
| NOTICE OF INTENTION TO: | | SU | IBSEC | QUENT R | | | | |
| PERFORM REMEDIAL WORK PLUG AND ABANDON | | REMEDIAL WO | DRK | | ALTER | RING CASI | NG 🗌 | |
| TEMPORARILY ABANDON | | COMMENCE D | RILLIN | G OPNS.□ | PLUG | AND | | |
| PULL OF ALTER CACING | | | | _ | ABANI | DONMENT | | |
| PULL OR ALTER CASING | | CASING TEST CEMENT JOB | AND | | | | | |
| OTHER: | | OTHER: | | | | | П | |
| 12. Describe proposed or completed operations. (Clearly state | | | give ne | rtinent dates | includin | g estimated | | |
| starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or | | | | | | | | |
| recompilation. | | | | | | | | |
| Four Star Oil and Gas proposes to plug and abandon the subject well according to the attached procedure: | | | | | | | | |
| 2 our our our proposes to prug une dominon the subject won according to the attached procedure. | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| OCT 2007 | | | | | | | | |
| | | | | | | | | |
| | | | | THE WALL | | | | |
| | | | | | ંદ, હુ | 67 | | |
| and the second of the second o | | | | | | | | |
| | | | | | 7.11.01.12 | منتطو | | |
| I hereby certify that the information above is true and complete to the best of my knowledge and belief. | | | | | | | | |
| V. A. h.a | | · | _ | | | 12/10 | حمالا | |
| SIGNATURE Ken Yackson T | TTLE_Reg | gulatory Special | list | | D | ATE 10 2 | 4103 | |
| Type or print name Ken Jackson Telephone No. (281) 561-4991 | | | | | | | | |
| (This space for State use) | Allan | AUIAA | | | <u> </u> | 7T 9 77 | 2003 | |
| APPPROVED BY SUPERVISOR DISTRICT #3 DATE | | | | | | • | PP A A A | |
| Conditions of approval, if any: | | | | | | | | |
| | | | | | | | | |

Ward A #1 Proposed P & A Procedure

- 1) Install and test rig anchors. Prepare blow pit.
- 2) MIRU. Conduct safety meeting with all personnel on location. N/U Relief line. Blow down well, and kill well with H2O if necessary. N/D Wellhead. N/U BOPE and test.
- 3) TOOH and tally tubing. RIH w/ gauge ring to 2915'. Set CIBP @ 2900'.
- 4) RIH W/tubing & tag CIBP @2900'. Load hole and pressure test to 500 PSI.
- 2500 5) Plug #1 (Charca) 2900'-2850'. 8 sx. POOH to 1910'.
- 6) Plug #2 (PC Fruitland) 1910'-1749'. 16sx. POOH to 980'.
- 7) Plug #3 (Kirtland) -980'-980'. 12sx. POOH to 333'
- 8) Plug #4 (333'- Surface) 27sx.

ND BOPE and RD floor. Dig cellar and cut off wellhead. Top off casing strings as needed. RD and MOL. Cut off anchors and install dry hole marker. Reclaim location.

PROPOSED WELL BORE DIAGRAM WARD A-1

