Form 3160-5 (August 2007)

UNITED STATES DEPARTMENT OF THE INTERIOR

BUREAU OF LAND MANAGEMENT

FORM APPROVED OMB NO. 1004-0135 Expires: July 31, 2010

5. Lease Serial No. NMSF080384B

SUNDR	Y	NO.	TICES	AND	REF	20	RTS	ON	WELLS	

Do not use this form for proposals to drill or to re-enter an abandoned well. Use form 3160-3 (APD) for such proposals.

6. If Indian, Allottee or Tribe Name

SUBMIT IN TRIPLICATE - Other instruc	tions on reverse side.	7 If Unit or CA/Agreement, Name and/or No.		
Type of Well	E .	8 Well Name and No. HICCUP A 2R		
2. Name of Operator Contact: MERRION OIL & GAS CORP E-Mail: pthompsor	PHILANA THOMPSON n@merrion.bz	9. API Well No. 30-045-31009-00-S1		
3a. Address 610 REILLY AVE FARMINGTON, NM 87401-2634	3b. Phone No. (include area code) Ph: 505-324-5336 Fx: 505-324-5350	10. Field and Pool, or Exploratory BASIN FRUITLAND COAL		
4. Location of Well (Footage, Sec., T., R, M., or Survey Description,		11. County or Parish, and State		
Sec 3 T26N R12W SWSW 725FSL 986FWL		SAN JUAN COUNTY, NM		
12. CHECK APPROPRIATE BOX(ES) TO	INDICATE NATURE OF NOTICE, R	EPORT, OR OTHER DATA		

TYPE OF SUBMISSION	TYPE OF ACTION				
Notice of Intent ☐ Subsequent Report ☐ Final Abandonment Notice	☐ Acidize ☐ Alter Casing ☐ Casing Repair ☐ Change Plans ☐ Convert to Injection	Deepen Fracture Treat New Construction Plug and Abandon Plug Back	☐ Production (Start/Resume) ☐ Reclamation ☐ Recomplete ☑ Temporarily Abandon ☐ Water Disposal	☐ Water Shut-Off ☐ Well Integrity ☐ Other	

If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.)

Merrion Oil & Gas proposes to TA the following well per attached procedure

Due to economic impact we had to SI the SWD Flush #1, the following well utilizes this SWD facility. We are currently in the process of reviewing this well for a possible horizontal sidetrack. MOG would like to request a TA status of 1 year to review procedures & economics.

TA approved unril 11/15/10

States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

2010 NOV 15'09

OIL COMS. DIV.

DIST. 3

14. I hereby certify tha	t the foregoing is true and correct Electronic Submission #77247 verified For MERRION OIL & GAS CO Committed to AFMSS for processing by ST	RP. se	ent to the Farmington			
Name (Printed/Type	PHILANA THOMPSON	Title	REGULATORY COMPLIANCE SPEC			
Signature	(Electronic Submission)	Date	11/12/2009			
	THIS SPACE FOR FEDERA	AL OR	STATE OFFICE USE			
Approved By STEPH	IEN MASON	Title	PETROLEUM ENGINEER	Date 11/16/200		
Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.			Office Farmington			



TEMPORARY ABANDONMENT PROCEDURE

Well Information						
Well:	Hiccup A # 2R	Field:	Basin Fruitland Coal			
	725 fsl & 986' fwl	Elevations:	6076'GL 60812'KB			
Location:	Sec 3, T26N, R12W San Juan Co., New Mexico	Depths:	PBTD @1562' KB			
API:	30-045-31009	Date:	05-Nov-2009			
	(4-1/2" 11.6# J55 LTC Production csg @ 1602 See schematic for tog. detail	Engineer:	J. Ryan Davis (505:245:3292)			
Perforation	1352'-1369' KB 3's	pf total 51 holes				
	Addition	nal Perforations				
Perforation						

Version 1 – Procedure subject to change based on changing well conditions.

Project Scope

Due to current economic conditions the above mentioned well is to be temporarily abandoned.

Prepare Well for TA

- 1. MIRU
- 2. Blow dn csg and tbg if pressure present
- 3. TOOH w/ rod string and lay dn (55-3/4" plain)
- 4. ND wellhead and NU BOP
- 5. TOOH w/ 1411' of 2-3/8" tbg (42 jts), Tally out
- 6. Round trip 4 1/2" csg scrapper
- 7. Contact OCD and BLM to witness test and arrange for chart recorder.

Set BP and Pressure Test


- 8. RU wireline and RIH w/ 4 1/2" CIBP and set @ 1302'KB (between 1252'-1302')
- 9. ND BOP and NU wellhead
- 10. Pickle the csg w/ conditioned, non-corrosive fluid
- 11. Pressure test csg to 500 psi for 30 min. Use 1000# max spring and 24 hr chart
- Conduct bradenhead test
- 13. Haul excess tbg to yard (MT Required JRD)
- 14. RDMOL
- 15. Follow up to ensure all necessary paper work has been completed and submitted (ie. Sundry notice, MT, BH Test, etc..)



TEMPORARY ABANDONMENT PROCEDURE

Merrion Oil & Gas Corporation Wellbore Schematic

Hiccup A No. 2R





TEMPORARY ABANDONMENT PROCEDURE

Merrion Oil & Gas Corporation Wellbore Schematic

