

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

FORM APPROVED  
OMB NO. 1004-0137  
Expires July 31, 2010

**SUNDRY NOTICES AND REPORTS ON WELLS**

**Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.**

**SUBMIT IN TRIPLICATE - Other instructions on page 2**

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

ENERGEN RESOURCES CORPORATION

3a. Address

2010 Afton Place Farmington, NM 87401

3b. Phone No. (include area code)

505.325.6800

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

890' FSL, 1750' FEL, Sec.02, T26N, R03W

5. Lease Serial No.

Jicarilla Contract 96

6. If Indian, Allottee or Tribe Name

Jicarilla Apache

7. If Unit or CA/Agreement, Name and/or No.

8. Well Name and No.

Jicarilla 96 # 9

9. API Well No.

30-039-82347

10. Field and Pool, or Exploratory Area

Tapacito Pictured Cliffs

11. County or Parish, State

Rio Arriba NM

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- |   |  |  |   |
|---|--|--|---|
| <input type="checkbox"/> Acidize              | <input type="checkbox"/> Deepen                      | <input type="checkbox"/> Production (Start/Resume) | <input type="checkbox"/> Water Shut-Off |
| <input type="checkbox"/> Alter Casing         | <input type="checkbox"/> Fracture Treat              | <input type="checkbox"/> Reclamation               | <input type="checkbox"/> Well Integrity |
| <input type="checkbox"/> Casing Repair        | <input type="checkbox"/> New Construction            | <input type="checkbox"/> Recomplete                | <input type="checkbox"/> Other _____    |
| <input type="checkbox"/> Change Plans         | <input checked="" type="checkbox"/> Plug and Abandon | <input type="checkbox"/> Temporarily Abandon       |   |
| <input type="checkbox"/> Convert to Injection | <input type="checkbox"/> Plug Back                   | <input type="checkbox"/> Water Disposal            |   |

13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleat horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleat in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the final site is ready for final inspection.)

Energen Resources plans to Plug and Abandon the Jicarilla 96 #9 according to the attached procedure.

RCVD JAN 5 '10  
OIL CONS. DIV.  
DIST. 3

Notify NMOC D 24 hrs  
prior to beginning  
operations

14. I hereby certify that the foregoing is true and correct

Name (Printed/Typed)

Martin Cabrera

Title District Engineer

Signature

Date 12/18/2009

**THIS SPACE FOR FEDERAL OR STATE OFFICE USE**

Approved by

Original Signed: Stephen Mason

Title

Date

JAN 05 2010

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Office

Title 18 U.S.C. Section 1001, and Title 43 U.S.C. Section 1212, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

NMOC D

## PLUG AND ABANDONMENT PROCEDURE

November 9, 2009

### Jicarilla 96 #9

Gavillan Pictured Cliffs

890' FSL and 1750' FEL, Section 2, T26N, R3W  
Rio Arriba County, New Mexico / API 30-039-82347

Lat: N \_\_\_\_\_ / Lat: W \_\_\_\_\_

Note: All cement volumes use 100% excess outside pipe and 50' excess inside. The stabilizing wellbore fluid will be 8.3 ppg, sufficient to balance all exposed formation pressures. All cement will be Class B, mixed at 15.6 ppg with a 1.18 cf/sx yield.

1. Install and test location rig anchors. Prepare a blow pit. Comply with all State, BLM, and Operator safety regulations. MOL and RU daylight pulling unit. Conduct safety meeting for all personnel on location. Record casing, tubing and bradenhead pressures. NU relief line and blow down well. Kill well with water as necessary and at least pump tubing capacity of water down the tubing. ND wellhead and NU BOP. Function test BOP.

2. Rods: Yes \_\_\_\_\_, No X, Unknown \_\_\_\_\_.  
Tubing: Yes X, No \_\_\_\_\_, Unknown \_\_\_\_\_, Size 1.25", Length 3710'  
Packer: Yes \_\_\_\_\_, No X, Unknown \_\_\_\_\_, Type \_\_\_\_\_

If this well has rods or a packer, then modify the work sequence in step #2 as appropriate.

3. **Plug #1 (Pictured Cliffs interval, Fruitland, Kirtland and Ojo Alamo tops, 3541' – 3198')**:  
RIH and set a 2.875" wireline CIBP at 3541'. TIH with tubing and tag. Load casing with water and circulate well clean. Attempt to pressure test casing. If casing does not test, then spot or tag subsequent plugs as appropriate. Mix ~~14~~<sup>40</sup> sxs Class B cement and spot a balanced plug (in 2 stages) above CIBP to isolate the Pictured Cliffs interval then cover through the Ojo Alamo top. TOH with tubing.

4. **Plug #3 (Nacimiento top, <sup>27</sup>2098' – <sup>27</sup>1998')**: Perforate 3 HSC squeeze holes at <sup>2027</sup>2098'. If casing tested, then establish rate into squeeze holes. Set a 2.875" cement retainer at ~~2048'~~<sup>2048'</sup>. Establish rate below CR. Mix and pump 40 sxs Class B cement, squeeze 35 sxs outside the casing and leave 5 sxs inside the casing to cover the Nacimiento top. TOH and LD tubing.

5. **Plug #4 (Surface, 378' – Surface)**: Perforate 3 HSC squeeze holes at 378'. Establish circulation to surface out the 2.875" casing and bradenhead valve, circulate the BH annulus clean. Mix and pump approximately 95 sxs Class B cement down 2.875" casing and circulate good cement out bradenhead. SI well and WOC.

6. ND BOP and cut off wellhead below surface casing flange. Install P&A marker with cement to comply with regulations. RD, MOL and cut off anchors. Restore location per BLM stipulations.

The Jicarilla Apache Nation requires 45 days to evaluate this well beginning from Jan 4, 2010 in order to determine if they would like to assume ownership of the well. If the Jicarilla Apache Nation has not contacted your office before the end of the 45 days you may proceed with plugging operations.

**UNITED STATES DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT  
FARMINGTON DISTRICT OFFICE  
1235 LA PLATA HIGHWAY  
FARMINGTON, NEW MEXICO 87401**

Attachment to notice of  
Intention to Abandon:

Re: Permanent Abandonment  
Well: 9 Jicarilla 96

**CONDITIONS OF APPROVAL**

1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal and Indian Lease."
2. Farmington Office is to be notified at least 24 hours before the plugging operations commence (505) 599-8907.
3. The following modifications to your plugging program are to be made:
  - a) Bring the top of the Pictured Cliffs/Fruitland/Kirtland/Ojo Alamo plug to 3140'.
  - b) Place the Nacimiento plug from 2027' – 1927' inside and outside the 2 7/8" casing

You are also required to place cement excesses per 4.2 and 4.4 of the attached General Requirements.

Office Hours: 7:45 a.m. to 4:30 p.m.