Submit 3 Copies To Appropriate District State of New Mexico Form C-103 Office June 19, 2008 Energy, Minerals and Natural Resources District I WELL API NO. 1625 N. French Dr., Hobbs, NM 88240 30-039-30861 District II OIL CONSERVATION DIVISION 1301 W. Grand Ave., Artesia, NM 88210 5. Indicate Type of Lease 1220 South St. Francis Dr. District III STATE [FEE X 1000 Rio Brazos Rd., Aztec, NM 87410 Santa Fe, NM 87505 6. State Oil & Gas Lease No. District IV 1220 S. St. Francis Dr., Santa Fe, NM 87505 SUNDRY NOTICES AND REPORTS ON WELLS 7. Lease Name or Unit Agreement Name (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A Jeffrey Spill DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) 8. Well Number #1 1. Type of Well: Oil Well Gas Well Other 2. Name of Operator 9. OGRID Number Approach Operating, LLC 248343 10. Pool name or Wildcat 3. Address of Operator 6500 West Freeway, Suite 800, Fort Worth, TX 76116 WC: Mancos 4. Well Location 2086 feet from the South 1762 Unit Letter line and feet from the Section 09 Township 27N Range 04E NMPM Rio Arriba County 11. Elevation (Show whether DR, RKB, RT, GR, etc.) 7328' GR 12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: PERFORM REMEDIAL WORK □ PLUG AND ABANDON REMEDIAL WORK ALTERING CASING [] Х **TEMPORARILY ABANDON** CHANGE PLANS COMMENCE DRILLING OPNS. P AND A PULL OR ALTER CASING MULTIPLE COMPL CASING/CEMENT JOB DOWNHOLE COMMINGLE OTHER: OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion. RCVD JIM 11'10 ATL COMS. DIV. Approach Operating, LLC proposes to alter the approved drilling plan as follows: MST. B Drill a 12-1/4" hole and set 8-5/8", 32#, J-55, ST&C casing at 350' and cement to the surface with 245 sx (289 cu.ft.) of Type III cement with ¼ pps celloflake, and 3% CaCl₂. 100% excess to circulate cement to surface. Drill a 6-1/4" hole with air-mist through the Greenhorn formation as determined by a mud logger. Fill the open hole with frac sand from TD to above any oil shows. Run 5-1/2", 15.5#, J-55, ST&C casing from the top of the sand fill to surface. Cement to surface with a lead cement consisting of Type III cement with 2% SMS and ¼ pps celloflake and tail with 75 sx (89 cu.ft.) of Type III cement with ¼ pps celloflake. Cement volumes calculated to provide a 100% excess to circulate cement to surface. Drill out the shoe joint and clean out the open hole to TD with a 4-3/4" bit with air-mist. Run a 4" flush joint slotted liner from TD to 100' above the 5-1/2" casing shoe. No liner hanger will be used and the 4" liner will not be cemented. Rig Release Date: Spud Date: I hereby certify that the information above is true and complete to the best of my knowledge and belief. **SIGNATURE** TITLE Agent/Engineer DATE 6/4/10 E-mail address: paul@walsheng.net PHONE: (505) 327-4892 — Cas Inspector, Type or print name Paul C. Thompson, P.E. For State Use Only APPROVED BY: TITLE DATE Conditions of Approval (if any):