UNITED STATES
DEPARTMENT OF THE INTERIOR

BUREAU OF LAND MANAGEMENT

RECEIVED

JUL 21 2010

σ,	ureau	mington Field Office u of Land Management
	5.	Lease Number Cont 65
1. Type of Well GAS	6.	lf Indian, All. or Tribe Name
2. Name of Operator	7.	Unit Agreement Name
CONOCOPHILLIPS COMPANY		
3. Address & Phone No. of Operator	8.	Well Name & Number Jicarilla 22-2
PO Box 4289, Farmington, NM 87499 (505) 326-9700	9.	API Well No.
4. Location of Well, Footage, Sec., T, R, M		30-039-20192
	10.	Field and Pool
Surf: Unit J (NWSE), 2140' FSL & 1980' FEL, Section 21, T25N, R4W, NMPM	11.	Lindrith Gallup/DK Wes County and State Rio Arriba Co., NM
12. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OTH Type of Submission Type of Action	IER	DATA
X Notice of Intent Abandonment Change of Plans Recompletion New Construction	<u>X</u>	Other - P&A
Subsequent Report Plugging Non-Routine Fracturing Casing Repair Water Shut off		RCVD JUL 26 '10
Final Abandonment Altering Casing Conversion to Injection		OIL CONS. DIV. DIST. 3
13. Describe Proposed or Completed Operations ConocoPhillips Company wishes to P&A subject well per attached procedures and well bore scheme. 14. I hereby certify that the foregoing is true and correct. Signed		
CONDITION OF APPROVAL, if any:		Date

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction



PLUG AND ABANDONMENT PROCEDURE

July 12, 2010

Jicarilla Apache #22-2

West Lindrith Gallup/Dakota

2140' FSL, 1980' FEL, Section 21, T25N, R4W, Rio Arriba County, New Mexico API 30-039-20192 / Long: 107° 15' 18.288" W / Lat: 36° 23' 2.08" N

Note: All cement volumes use 100% excess outside pipe and 50' excess inside. The stabilizing wellbore fluid will be 8.3 ppg, sufficient to balance all exposed formation pressures. All cement will be Class B, mixed at 15.6 ppg with a 1.18 cf/sx yield.

- 1. This project requires a NMOCD C-144 CLEZ Closed-Loop System Permit for the use of an A-Plus steel tank to handle waste fluids circulated from the well and cement wash up.
- Install and test location rig anchors. Comply with all NMOCD, BLM, and Operator safety
 regulations. MOL and RU daylight pulling unit. Conduct safety meeting for all personnel on
 location. Record casing, tubing and bradenhead pressures. NU relief line and blow down well.
 Kill well with water as necessary and at least pump tubing capacity of water down the tubing. ND
 wellhead and NU BOP. Function test BOP.

3.	Rods: Yes, NoX, Unknown
	Tubing: Yes X , No, Unknown , Size, Length, Length, Length
	Packer: Yes, No_X_, Unknown, Type
4	If this well has rade as a packer, then modify the work sequence in stan #2 as appropriate

- If this well has rods or a packer, then modify the work sequence in step #2 as appropriate.
- NOTE: BLM requires a CBL log to be run on all wells where the cement did not circulate to surface or where a T.S. or CBL log was not previously run. This procedure is prepared with the understanding that it may be modified based on the TOC from the CBL.
- 6. Plug #1 (Dakota/Gallup perforations and top, 6638' 6558'): RIH and set CR at 6638'. Pressure test tubing to 1000 PSI. <u>Pressure test casing to 800 PSI. If casing does not pressure test, then spot or tag subsequent plugs as appropriate.</u> Spot 17 sxs Class B cement and spot a balanced plug inside the casing above CR to isolate the Dakota and Gallup intervals. PUH.
- 7. Plug #2 (Mesaverde top, 5076' 4976'): Mix 17 sxs Class B cement and spot a balanced plug inside casing to cover the Mesaverde top. TOH with tubing.

 -Chacka Plug -Top 4135 Plug 4285-4186 34/6 2763
 - 8. Plug #3 (Picture Cliffs, Fruitland, Kirtland and Ojo Alamo tops, 3443' 2925'): Perforate 3 HSC holes at 3443'. TIH and set a CR at 3593'. Establish a rate into the squeeze holes. Mix 258 sxs Class B cement, squeeze 192 sxs outside the casing and leave 76-sxs inside casing to cover through the Ojo Alamo top. TOH with tubing.
 - 9. Plug #4 (Nacimiento top, 1296' 1495'): Perforate 3 HSC holes at 1295'. TIH and set a CR at 1245'. Establish a rate into the squeeze holes. Mix 47 sxs Class B cement, squeeze 30 sxs outside the casing and leave 17 sxs inside casing to cover the Nacimiento top. TOH and LD tubing.
 - Plug #5 (8.625" Surface casing shoe, 253' to Surface): Perforate 3 squeeze holes at 253'.
 Establish circulation out bradenhead with water and circulate the BH annulus clean. Mix

approximately $85~\rm sxs$ Class B cement and pump down the 5.5" casing to circulate good cement out bradenhead. Shut in well and WOC.

11. ND BOP and cut off wellhead below surface casing flange. Install P&A marker with cement to comply with regulations. RD, MOL and cut off anchors. Restore location per BLM stipulations.

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT FARMINGTON DISTRICT OFFICE

1235 LA PLATA HIGHWAY FARMINGTON, NEW MEXICO 87401

Attachment to notice of Intention to Abandon:

Re: Permanent Abandonment

Well: 2 Jicarilla 22

CONDITIONS OF APPROVAL

- 1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal and Indian Lease."
- 2. Farmington Office is to be notified at least 24 hours before the plugging operations commence (505) 599-8907.
- 3. The following modifications to your plugging program are to be made:
- a) Bring the top of the Dakota/Gallup plug to 6283'.
- b) Place the Pictured Cliffs/Fruitland/Kirtland/Ojo Alamo plug from 3416' 2763' inside and outside the $5\frac{1}{2}$ " casing.
- c) Place the Nacimiento plug from 1554' 1454' inside and outside the 5 1/2" casing.

add Chaira Plug 4285-4185

You are also required to place cement excesses per 4.2 and 4.4 of the attached General Requirements.

Office Hours: 7:45 a.m. to 4:30 p.m.