Form 3160-5 (August 1999)

# UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED OMB NO. 1004-0135 Expires: November 30, 2000

5	Lease Serial No.	Ī
J.		
	NIMCEO70502	

SUNDRY I Do not use thi abandoned wel	NMSF078502  6. If Indian, Allottee or Tribe Name					
SUBMIT IN TRII	7. If Unit or CA/Agreement, Name and/or No.					
<ol> <li>Type of Well</li> <li>Oil Well  Gas Well  ☐ Oth</li> </ol>	er	282	DEC 2002	8. Well Name and No. VANDERWART A	6	
2. Name of Operator BP AMERICA PRODUCTION	COntact:	MARY COPLEY E-Mail: corley(ril@bp.c	EY A CONTRACT 9. API Well No.			
3a. Address P. O. BOX 3092 HOUSTON, TX 77253		3b. Phone No. Fineluck Ph: 281.366.4491 Fx: 281.366.0700	¥491 BLANCO MESAVERDE			
4. Location of Well <i>(Footage, Sec., T.</i> Sec 24 T29N R8W NENE 099 36.71559 N Lat, 107.62187 W	OFNL 0990FEL		maken in the second	11. County or Parish, and State SAN JUAN COUNTY, NM		
12. CHECK APPR	ROPRIATE BOX(ES) TO	INDICATE NATU	IRE OF NOTICE, R	EPORT, OR OTHER	R DATA	
TYPE OF SUBMISSION			TYPE OF ACTION			
Notice of Intent	☐ Acidize	Deepen	☐ Product	tion (Start/Resume)	■ Water Shut-Off	
	☐ Alter Casing	☐ Fracture Tre	at 🔲 Reclam	ation	■ Well Integrity	
☐ Subsequent Report	□ Casing Repair	☐ New Constr	uction	plete	<b>⊠</b> Other	
☐ Final Abandonment Notice	□ Change Plans	☐ Plug and Ab	andon 🔲 Tempo	rarily Abandon	Workover Operations	
	☐ Convert to Injection	□ Plug Back		Disposal		
If the proposal is to deepen directional Attach the Bond under which the wor following completion of the involved testing has been completed. Final Abdetermined that the site is ready for final BP America Production Compathe Menefee and Lewis Shale	k will be performed or provide operations. If the operation research manufacture in the second secon	the Bond No. on file with sults in a multiple comple ed only after all requirem permission to add pa	n BLM/BIA. Required su tion or recompletion in a ents, including reclamation y and fracture stimul	bsequent reports shall be a new interval, a Form 3160 n, have been completed, a	filed within 30 days 0-4 shall be filed once	
14. I hereby certify that the foregoing is  Con	Electronic Submission #	N PRODUCTION CO,	sent to the Farmington albert on 11/26/2002 (0	n 03MXH0213SE)		
Name (Printed/Typed) MARY CO	RLEY	Title	AUTHORIZED REF	PRESENTATIVE		
Signature (Electronic S		Date	10/30/2002			
	THIS SPACE FO	R FEDERAL OR	STATE OFFICE U	SE		
_Approved By /S/ Jim Lovan	6)	Title			Date	
Conditions of approval, if any, are attached certify that the applicant holds legal or equivalent would entitle the applicant to condu	itable title to those rights in the					
Title 18 U.S.C. Section 1001 and Title 43	U.S.C. Section 1212, make it a	crime for any person kno	wingly and willfully to m	ake to any department or	agency of the United	

# Vandewart A #3 Payadd Procedure

#### Procedure:

- 1. Check anchors. MIRU workover rig.
- 2. Check and record tubing, casing, and bradenhead pressures.
- 3. Blow down well. Kill with 2% KCL water ONLY if necessary.
- 4. Nipple down WH. NU BOPs.
- 5. Tag for fill and tally OH with 2-3/8" production tubing currently set at 5778'.
- 6. RU WL unit. Run GR log across Menefee and Lewis Shale from 4500' 5800' to select perforations.
- 7. TIH with bit and scraper for 4-1/2" casing to 5800'.
- 8. RU WL unit. RIH with 4-1/2" CIBP. Set CIBP at 5775'.
- 9. RIH with 3-1/8" casing guns with Schlumberger's Prospector, select-fire charge. Perforate Menefee formation (correlate to GR log).

## Menefee perforations, 2 spf:

To be determined

- 10. RIH with 2-7/8" frac string and 4-1/2" packer. Set packer at 5525'.
- 11. Spearhead 500 gal 15% HCL, establish injection rate, and proceed with fracture stimulation according to Schlumberger schedule.
- 12. Flowback frac immediately.
- 13. Release packer and TOH with frac string and packer. LD frac string.
- 14. RU WL unit. RIH with 4-1/2" CIBP. Set CIBP at 5225'.
- 15. Pressure test casing to 2500 psi
- 16. RIH with 3-1/8" casing guns with Schlumberger's Prospector, select-fire charge. Perforate Lewis Shale formation (correlate to GR log).

### Lewis Shale perforations, 2 spf:

To be determined

- 17. RU frac equipment and install wellhead isolation tool. Use 2% KCL-N2 foam in fracture stimulation.
- 18. Spearhead 500 gal 15% HCL, establish injection rate, and proceed with fracture stimulation according to Schlumberger schedule.
- 19. Flowback frac immediately.
- 20. TIH with tubing and bit. Cleanout fill and drill bridge plugs. Cleanout fill to PBTD at 5992'. Blow well dry at PBTD.
- 21. Rabbit tubing and RIH with 2-3/8" production tubing.
- 22. Land 2-3/8" production tubing at 5900'.
- 23. ND BOP's. NU WH. Test well for air. Return well to production.

### Vandewart A #3

Sec. 13 T29N R8W API#: 30-045-08202

