Form 3160-5 (June 1990)

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED							
Budget Bureau No. 1004-0135							
Expires: March 31, 1993							

		_			<u>. r</u>						,	
i.	L	ca	se	D	es	ig	na	tion	and	Se	rial	No
٠.	_	_	_	_	_	_	_	_				

••••	NM 052931			
Do not use this form for proposals to dri	AND REPORTS ON WELLS If or to deepen or reentry to a different reservoir If PERMIT—" for such proposals	6. If Indian, Allottee or Tribe Name		
SUBMIT	7. If Unit or CA, Agreement Designation 8. Well Name and No. HANSON 27			
1. Type of Well X Oil Well Gas Well Other 2. Name of Operator				
BC&D OIL & GAS, INC. 3. Address and Telephone No.	9. API Well No. 30-031-20444			
PO BOX 837, HOBBS, NM 88241 4. Location of Well (Footage, Sec., T., R., M., or Survey Des	10. Field and Pool, or Exploratory Area HOSPAH UPPER SAND SOUTH 11. County or Parish, State			
660 FSL, 1980 F/kL, SEC. 6, T1	MCKINLEY, NM			
) TO INDICATE NATURE OF NOTICE, REPO	ORT, OR OTHER DATA		
TYPE OF SUBMISSION	TYPE OF ACTION	N		
Notice of Intent	Abandonment Recompletion	Change of Plans New Construction		
L_J Subsequent Report Final Abandonment Notice	Plugging Back Casing Repair Altering Casing Other	Non-Routine Fracturing Water Shut-Off Conversion to Injection Dispose Water		
	DECEIVED APR 1 1 1507 OUL COMB. DIV.	WELL BY FOLLOWING THE RECEIVED 97 MAR 12 AM 11: 16 070 FARMINGTON, NM		
14. I hereby certify that the foregoing is true and respect	Title PRESIDENT	3/4/97		
		Date		

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

HANSON 27

Request to plug & abandon

- 1. TIH with 2 7/8" tbg openended, Tag PBTD @ 1478'. Mix, pump & spot 24 sx Class B cmt @ 1478', POH to 1300', circulate hole clean, shut down overnite. WOC
- 2. TIH with tbg. Tag cmt top at 1333', mix and pump 9.0 PPG mud to fill csg. POH with tbg.
- 3. TIH with $5\frac{1}{2}$ " casing cutters, cut casing at 1000' from surface, POH with tbg., POH and lay down $5\frac{1}{2}$ " csg.
- 4. TIH with 2 7/8' tbg. to 600', mix and pump 25 sx class B neat (Plug @ 600'-575') POH with tbg. Shut-down overnite, WOC
- 5. TIH with tbg., Tag cmt plug @ 575', mix and pump 9.0 PPG mud from 575'-290', POH with tubing to 290', mix and pump 25 sx class B cmt neat (plug @ 290'-265'), POH with tbg., shut down overnite, WOC.
- 6. TIH with tbg, Tag cmt plug @265', mix and pump 9.0 PPG mud 265'-140', POH with tbg to 140', mix and pump 65 sx class B neat (plug @ 140'-surface) POH with tbg. Shut down overnite, WOC
- 7. Tag surface plug and top off csg if necessary. Install P&A marker with well ID, rehabilitate to surface location to BLM requirements.