

State of New Mexico  
Energy, Minerals and Natural Resources Department  
Oil Conservation Division

Sundry Notices and Reports on Wells

1. Type of Well  
OIL

2. Name of Operator  
Geo Engineering

3. Address & Phone No. of Operator  
P. O.Box 2966  
Santa Fe, NM 87505

4. Location of Well, Footage, Sec., T, R, M  
Sec. 28 T-20-N, R-9-W, NMPM, McKinley County  
Unit B, (20' north of State # 2)\_

**RECEIVED**  
FEB 17 1998

**OIL CON. DIV.**  
DIST. 3

API # (assigned by OCD)

5. Lease Number

6. State Oil & Gas Lease #

7. Lease Name/Unit Name  
State

8. Well No.  
#2 (Unknown)

9. Pool Name or Wildcat

10. Elevation:

**Type of Submission**

☐ Notice of Intent

☒ Subsequent Report

☐ Final Abandonment

**Type of Action**

☒ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☐ Other -

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut off

☐ Conversion to Injection

**13. Describe Proposed or Completed Operations**

A-Plus Well Service, contractor, plugged and abandoned said well according to the attached Daily Report on February 11, 1998.

This work was completed under State of New Mexico Contract No. 98-521.25-059.

SIGNATURE William F. Clark Contractor

February 12, 1998

(This space for State Use)

Approved by Gary Robinson

DEPUTY OIL & GAS INSPECTOR, DIST. #3  
Title

Date MAR 13 1998

## Daily Report

## A - PLUS WELL SERVICE

13945

P.O. BOX 1979 • FARMINGTON, NM 87499  
505-325-2627 • FAX (505) 325-1211

Rig No \_\_\_\_\_

20' N. of STATE #2

Date

2/5/98 - 2/11/98

Well No UNKNOWN STATE #2

Location

Red Mtn

Company

Geo Eng.

FROM	TO	DESCRIPTION OF OPERATION
2-5-98		
1:30	2:30	Run wh to 309' & tag
2-6-98		
9AM	9:30	Rig up PT 105 Pump down 5' csg. w/ 10 BBL. AT 250 PSI 1 1/2 BPM (? Perf 520 UNKNOWN)
9:30	10AM	Plug #1 Mix 30 SX Pump Top down Displace cement to 309' WOC.
2PM	2:30	Pressure Test csg to 500 PSI ok. Then Perf 2 Holes AT 299' (Tag cement) used 2-2 1/8 By wire shot
2:30	2:45	Pump in to Perf at 299' w/ 10 BBL AT 100 PSI AT 1 1/2 BPM NO circulation Behind 5' csg
2:45	3PM	Plug #2 Mix 36 SX Pump down 5' csg. displace to 30' shut well IN w/ 200 PSI
3PM	3:30	Perf 2 Hole AT 30' 2 1/8 By wire Pump 1 BBL NO circulation Behind 5' csg Pump 2 BBL NO circulation Behind 5' csg Pumping AT 0 PSI Plug #3 Mix 20 SX cement Pump into Perf at 30' shut well IN
2:30	4PM	Wash PT 105 move off Loc
2/11/98	1/2	make & set marker

Fuel &amp; Motor Oil \_\_\_\_\_ Water Hauled \_\_\_\_\_

Rental Equipment \_\_\_\_\_ Cement Retainers \_\_\_\_\_

Cementing Plug #1 30 SX P-2 36 SX P-3-20 SXWireline 2-2 1/8 By wire AT 299' 2-2 1/8 By wire AT 30'