

State of New Mexico  
Energy, Minerals and Natural Resources Department  
Oil Conservation Division

**Sundry Notices and Reports on Wells**

API # (assigned by OCD)

30-031-60028

1. **Type of Well**  
OIL

5. **Lease Number**  
Fee

6. **State Oil & Gas Lease #**

2. **Name of Operator**  
Geo Engineering

7. **Lease Name/Unit Name**  
Santa Fe Pacific I

8. **Well No.**  
#12

3. **Address & Phone No. of Operator**  
P.O.Box 2966  
Santa Fe, NM 87505

9. **Pool Name or Wildcat**

4. **Location of Well, Footage, Sec., T, R, M**  
Sec. 20 T-20-N, R-9-W, NMPM, McKinley County  
Unit P, 1058' FSL and 860' FEL

10. **Elevation:**

**Type of Submission**

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment

**Type of Action**

☒ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☐ Other -

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut off

☐ Conversion to Injection

**13. Describe Proposed or Completed Operations**

A-Plus Well Service, contractor, will plug and abandon said well according to the attached procedure prepared by NMOCD.

This work will be in accordance with State of New Mexico Contract No. 98-521.25-059.

**RECEIVED**  
JAN 22 1998

**OIL CON. DIV.**  
DIST. 3

SIGNATURE

*William F. Clark*  
William F. Clark

Contractor

December 30, 1997

(This space for State Use)

Approved by

*Johnny Robinson*

DEPUTY OIL & GAS INSPECTOR, DIST. #3

Title

Date

JAN 22 1998

COMPANY Geo Engineering		PROPERTY NAME Santa Fe Pacific I	WELL NO. # 12
DATE	LOCATION (ULSTR) P-20-20N-09W	FOOTAGE	
API NO.		POOL	

  

2" thg with a 2" Tee 1 1/2 feet above ground level	

  

<p>CASING RECORD:</p> <p>2" csg. @ 436'</p> <p>calc. T.O.C @ 360'</p>	<p>360'</p> <p>calc. T.O.C.</p> <p>8 5/8\"</p> <p>436'</p> <p>csg.</p>
---	---

  

O.H. 483'	
--------------	--

<b>COMPANY</b> Geo Engineering		<b>PROPERTY NAME</b> Santa Fe Pacific I		<b>WELL NO.</b> # 12
<b>DATE</b>	<b>LOCATION (ULSTR)</b> P-20-20N-09U	<b>FOOTAGE</b>		
<b>API NO.</b>		<b>POOL</b>		

  

2" tbg with a 2" Tee  
1 1/2 feet above ground level

  

**CASING RECORD:**

2" csg. @ 436'  
calc. T.O.C @ 360'

1. Determine depth of well
2. If depth of well is 300' or more continue with procedure. If not clean out csg. to 300'
3. Perf. @ 300' & 30'. Est. circ. to the surf.
4. B.H. with slickline & load csg. with cement
5. P.H. with slickline & pump down csg. + cinc cement to the surf.
6. Install dry hole marker

  

360'  
-----  
calc.  
T.O.C.

85x5.  
436'  
-----  
2" csg.

O.H.  
483'