

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE\*  
(Other instructions on reverse side)

Form approved.  
Budget Bureau No. 42-R1424

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER		5. LEASE DESIGNATION AND SERIAL NO. CONTRACT NO. 160	
2. NAME OF OPERATOR DYNA RAY OIL AND GAS CO., INC.		6. IF INDIAN, ALLOTTEE OR TRIBE NAME JICARILLA	
3. ADDRESS OF OPERATOR 4101 E. Louisiana Avenue, Denver, Colorado, 80222		7. UNIT AGREEMENT NAME JICARILLA E 160	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1040' from west line 1170' from south line		8. FARM OR LEASE NAME JICARILLA E 160	
14. PERMIT NO.		9. WELL NO. 3	
15. ELEVATIONS (Show whether DF, RT, OR, etc.) 7342 KB		10. FIELD AND POOL, OR WILDCAT SO BLANCO, PC	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA 12-23N-2W	
		12. COUNTY OR PARISH RIO ARriba	
		13. STATE NEW MEXICO	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Well is non-productive and we propose to abandon as follows:

1. Place 50 sacks of cement across perforations from 3061'-3123'.
2. Cut off 4 1/2" casing at 1610'. Pump 50 sacks of cement on top of 4 1/2" stub. Pull casing.
3. Pump 25 sacks of cement in 8 5/8" surface casing.
4. Erect dry hole marker.



RECEIVED

NOV 27 1970

GEOLOGICAL SURVEY

18. I hereby certify that the foregoing is true and correct

SIGNED

*J. J. Ray*

TITLE

*President*

DATE

*11-25-70*

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side