


| | |
|------------------------|---|
| NO. OF COPIES RECEIVED | 3 |
| DISTRIBUTION | |
| SANTA FE | 1 |
| FILE | 1 |
| U.S.G.S. | |
| LAND OFFICE | |
| OPERATOR | 1 |

NEW MEXICO OIL CONSERVATION COMMISSION



Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State ☐ **Federal** Fee ☐

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS DIST. 3

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

| | |
|---|--|
| 1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- 2. Name of Operator El Paso Natural Gas Company 3. Address of Operator Box 990, Farmington, New Mexico 4. Location of Well UNIT LETTER G 1800 FEET FROM THE North LINE AND 1700 FEET FROM THE East LINE, SECTION 23 TOWNSHIP 24N RANGE 2W NMPM. 15. Elevation (Show whether DF, RT, GR, etc.) 7358' GL | 7. Unit Agreement Name 8. Farm or Lease Name Federal 9. Well No. 2 10. Field and Pool, or Wildcat So. Elanco Pictured C. 12. County Rio Arriba |
|---|--|

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

| | | | |
|--|--|--|---|
| PERFORM REMEDIAL WORK <input type="checkbox"/> | PLUG AND ABANDON <input checked="" type="checkbox"/> | REMEDIAL WORK <input type="checkbox"/> | ALTERING CASING <input type="checkbox"/> |
| TEMPORARILY ABANDON <input type="checkbox"/> | CHANGE PLANS <input type="checkbox"/> | COMMENCE DRILLING OPNS. <input type="checkbox"/> | PLUG AND ABANDONMENT <input type="checkbox"/> |
| PULL OR ALTER CASING <input type="checkbox"/> | OTHER <input type="checkbox"/> | CASING TEST AND CEMENT JOBS <input type="checkbox"/> | |

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Due to non-commercial production it is intended to plug and abandon this well in the following manner:

Spot 30 sacks of cement to cover from 3380' up.

Determine free point of 5 1/2" casing. Shoot off casing at free point. Spot a 30 sack cement plug on the 5 1/2" casing stub, pull casing.

If there is not sufficient 5 1/2" casing free to make an economical recovery, the casing will not be shot off and no plug spotted.

Place a 10 sack cement plug and 4" x 4' plug and abandonment marker in the top of the surface casing.

will fill with heavy mud between cement plugs

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Original signed by Carl E. Matthews TITLE Petroleum Engineer DATE 10-11-67

APPROVED BY *Emmy C. Ames* TITLE SUPERVISOR DIST. #3 DATE OCT 11 1967

CONDITIONS OF APPROVAL, IF ANY: