

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name Lindrith Unit
2. Name of Operator El Paso Natural Gas Company	8. Farm or Lease Name Lindrith Unit
3. Address of Operator Box 990, Farmington, New Mexico	9. Well No. 21
4. Location of Well UNIT LETTER 0 , 800 FEET FROM THE South LINE AND 1600 FEET FROM THE East LINE, SECTION 5 , TOWNSHIP 24N , RANGE 2W , NMPM.	10. Field and Pool, or Wildcat S. Blanco Pictured Cliffs
15. Elevation (Show whether DF, RT, GR, etc.) 7171'GL, 7181'DF	12. County Rio Arriba

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Due to non-commercial production it is intended to plug and abandon this well in the following manner:

Spot 30 sack cement plug down tubing to cover perforations 3305 - 3354'.

Shoot off 5 1/2" casing at free point, spot 20 sack cement plug on stub. Recover 5 1/2" casing.

Put 10 sack cement plug in top of surface pipe and install 4" x 4' plug and abandonment marker.

Note: A hole in the casing at 2242' was squeezed with 150 sacks of cement during original operations.

In the event there is insufficient 5 1/2" casing free to be economically recoverable item #2 will be omitted.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original signed by
Carl E. Andrews

SIGNED _____ TITLE **Petroleum Engineer** DATE **4-15-65**

APPROVED BY *Emery Claws* TITLE *Sup. Dist. III* DATE **4-21-65**

CONDITIONS OF APPROVAL, IF ANY: