

DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

(Other instructions on reverse side)

Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT--" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5. LEASE DESIGNATION AND SERIAL NO. JICARILLA APACHE # 34	
2. NAME OF OPERATOR DOYLE E. BAXTER		6. IF INDIAN, ALLOTTEE OR TRIBE NAME JICARILLA APACHE TRIBE	
3. ADDRESS OF OPERATOR P.O. BOX 27 BLOOMFIELD, N.M. 87413		7. UNIT AGREEMENT NAME	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 1980' FNL & 660' FEL "H" SEC 33 T25N - R5W		8. FARM OR LEASE NAME	
14. PERMIT NO.		9. WELL NO. JICARILLA "C" # 22	
15. ELEVATIONS (Show whether DP, RT, OR, etc.) 6793 Gr.		10. FIELD AND POOL, OR WILDCAT OTERO GALLUP	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA SEC 33 T25N-R5W	
		12. COUNTY OR PARISH RIO ARRIBA	
		13. STATE NEW MEXICO	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>	WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETE <input type="checkbox"/>	FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
ABANDON OR ACIDIZE <input type="checkbox"/>	ABANDON* <input type="checkbox"/>	SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input checked="" type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANT <input type="checkbox"/>	(Other) <input type="checkbox"/>	

(Other) ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

P&A

Set cast iron bridge plug 6051'.

Ran tubing & set down on bridge plug. Pumped 12 cu. ft. cement (10 sacks) on top of bridge plug.

Pump & spot 23.60 Cu.ft. cement (20 sacks) from 5014 to 4864.

Pump & spot 23.60 cu. ft. cement (20 sacks) from 4297 to 4147.

P.O.H. perforate @ 2000 ft. W/4 shots.

T.I.H. pump & spot 56 cu. ft. cement (47 sacks) inside and out 5½ csq. @ 2000-1900.

P.O.H. Perforate @ 1350ft. W/4 shots

T.I.H. pump & spot 56 cu. ft. (47 sacks) inside & out 5½ csq. @ 1350-1200.

Pump & spot 46 cu. ft. cement (38 sacks) 355 to surface. Will install dry hole marker at some later date.

18. I hereby certify that the foregoing is true and correct

SIGNED D. E. Baxter

TITLE President

DATE 10/26/95

(This space for Federal or State office use)

APPROVED BY [Signature]
CONDITIONS OF APPROVAL, IF ANY

TITLE Chief, Lands and Mineral Resources

DATE NOV 6 1995

*See Instructions on Reverse Side