Form 3160-5 (June 1990)

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

Expires: March 31, 1993

J.	LEASE	Designation	and	•
F-	-റമറ	1536		

6. If Indian, Allottee or Tribe Name

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.

Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

7. If Unit or CA, Agreement Designation

1. Type of Well			
Oil Mell Gas Well Other	= -	8. Well Name and No.	
2. Name of Operator		Ha	all Federal 5
Texaco Exploration and Productio		API Well No.	
3 Address and Telephone No.	3(0039059220001	
3300 N. Butler, Farmington N.M.). Field and Pool, or Exploratory Area	
4 Location of Well (Footage, Sec., T., R., M., or Survey D	S	S. Blanco, Pictured Cliff	
Sec 21, T25N-R3W	11	. County or Parish, State	
1850' FNL and 790' FWL		R:	io Arriba, NM
CHECK APPROPRIATE BOX	(s) TO INDICATE NATU	JRE OF NOTICE, REPORT,	OR OTHER DATA
TYPE OF SUBMISSION		TYPE OF ACTION	
Notice of Intent	Abandonme	ent	Change of Plans
	Recomplete	ion	New Construction
Subseque u r Réport	Plugging B	łack	Non-Routine Fracturing
_ 45 nove - cat	Casing Rep	раіг	Water Shut-Off
Final Abandonment Notice	Altering Co	asing	Conversion to Injection
ON CONTRA	Other		Dispose Water (Note: Report results of multiple completion on Well
\			Completion or Recompletion Report and Log torm.)
3 Describe Proposed or Completed Operations (Clearly state al			proposed work. If well is directionally drilled.
give subsurface locations and measured and true vertice	cal depths for all markers and zones p	pertinent to this work.)*	

Texaco proposes to plug and abandon the subject well. The following procedure will be followed.

- 1. MIRUSU.
- 2. TOOH w/ Prod TBG. TIH w/ CMT RET. Set @ 3750'.
- 3. SQZ Pictured Cliffs perfs using 40 sx class "B" CMT.
- 4. Sting out of RET and spot 75 sx class "B" CMT on top of RET (Top of plug @ 3100'). Spot mud from 3100'-1000'. TOOH w/ TBG.
- 5. RU wireline and perf 4 SQZ holes @ 1000'.
- 6. Establish circ to surface through SQZ holes, and CMT to surface. Displace CMT to 800' inside CSG.


 If circ is not obtained, SQZ holes using 30 sx class B CMT. Leave
 minimum plug inside csg from 1000'-800'. RU wireline and perf 4 SQZ holes @ 160'. Establish circ

through SQZ holes and CMT to surface.

7. Spot mud from 800'-300' inside CSG. Spot CMT plug from surface-300'.

8. RDMOSU. Remove all surface equipment. Reclaim location, and erect P&A marker.


	SEE ATTOCHED FOR CONDITIONS OF APPROVAL	
14 I hereby certify that the foregoing is true and correct Signed J. C. T.	Area Manager	11/31/91
(This space for Federal or State office use) Approved by Conditions of approval, if any:	Title	110V 18 1991
Title 18 U.S.C. Section 1901, makes it a crime for any person for representations as to any matter within its jurisdiction.	knowingly and willfully to make to any department or agency of the UNNCOY:	nited States any Talse. Tictitious of traudulem statements





HALL FEDERAL No. 5

CURRENT WELLBORE CONDITIONS



UNITED STATES DEPARTMENT OF THE INTERIOR

FARMINGTON RESOURCE AREA 1235 LASPLATA HIGHWAY PARMINGTON NEW MEXICO 87401

Attachment to Notice of

Re: Permanent Abandonment

Intention to Abandon

Well: 5 Hall Federal

CONDITIONS OF APPROVAL

- 1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal Leases."
- 2. Mark Kelly with the Farmington Office is to be notified at least 24 hours before the plugging operations commence (505) 326-6201.
- 3. Blowout preventions equipment is required.
- 4. The following modifications to your plugging program are to be made (when applicable):

Office Hours: 7:45 a.m. to 4:30 p.m.

GENERAL REQUIREMENTS FOR

PERMANENT ABANDONMENT OF WELLS ON FEDERAL AND INDIAN LEASES -FARMINGTON RESOURCE AREA

1. Secure prior approval either on a Sundry Notice (Zorn 3160-5) or verbally from the Fluids Drilling & Production Section at this office before changing the approved plugging program.

- 2. Flugging: equipment. used; shall have separate mixing and displacement pumps and a calibrated tank to assure proper displacement of plugs. The Operator is responsible for providing all measuring devices needed to assure proper measurement of materials being used.
- 3. A proper tank or pit will be used to contain all fluids pumped from the well during plugging operations. Unattended pits are to be fenced.
- 4... All cement plugs are to be placed through tubing (or drillpipe) and shall be a minimum of 100 feet in length with 50% excess inside casing or 100% excess when plug is set in open hole or squeezed into perforations. 15.6#/gal slurry wedght is to be used when using class B neat cement or when CaCl2 is used. Use the recommended slurry weight of other type cements when they are used (Class C, Pozzolan etc.).
- 5. Any cement plugs placed when well is not full of fluid, or when well may ce taking fluid, (i.e. across perfs-unless bridge plug or retainer is used, across bad csg., or fresh water formations) will be tagged (touched) after cement has set to verify proper location.
 - 5a. Testing: The first plug below the surface plug shall generally be tested by either tagging the plug with the working pipe string, or pressuring to a minimum pump (surface) pressure of 1000 psig, with no more than a 10 percent drop during a 15-minute period (cased hole only). If the integrity of any other plug is questioned, it must be tested in the same manner. Also, any cement plug which is the only isolating. medium for a fresh water interval or a zone containing a valuable mineral deposit should be tested by tagging with the drill string.
 - 6. Mud must be placed between plugs. Plugging mud is to be made up with a minimum of 15 lbs/bbl of sodium bentonite, and a nonfermenting polymer. Minimum consistency of plugging mud must be 9 lbs/gal and with a minimum viscosity of 50 sec/qt. Fresh water is to be utilized for mixing mud.
 - 7. Following the placement of a cement plug, the withdrawl rate for at least the length of the cement plug shall not exceed 30 ft/min, in order to minimize the contamination of the plug.

- 8. Within 30 days after plugging work is completed, file a Sundry Notice (Subsequent Report of Abandonment, Form 3160-5), in quintuplicate with Area Manager, Bureau of Land Management, 1235 La Plata Highway, Farmington, NM 87401. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. Show date well was plugged.
- 9. All permanently abandoned wells are to be marked with a regulation marker (4" pipe extending 4' above the ground line) containing the information as specified in 43 CFR 3162.6(d). Unless otherwise approved.
- 10. After plugging work is completed the surface is to be rehabilitated in accord with instructions from the Fluids Surface Management Section of the Farmington Resource Area Office.

All above are minimum requirements. The period of liability under the bond of record will not be terminated until the lease is inspected and surface work approved.

Please advise this office when the well location is ready for final inspection.

Failure to comply with the above conditions of approval may result in an assessment for noncompliance and/or a Shut-in Order being issued pursuant to: 43 CFR 3163.1.

You are further advised that any instructions, orders or decisions issued by the Bureau of Land Management are subject to administrative review pursuant to 43 CFR 3165.3 and appeal pursuant to 43 CFR 3165.4 and 43 CFR 4.700.