

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER	2. NAME OF OPERATOR TEXACO INC. (505) 325-4397	3. ADDRESS OF OPERATOR 3300 N. Butler Farmington, NM 87401	4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 990' FNL and 990' FEL Sec 19	5. LEASE DESIGNATION AND SERIAL NO SF-079601	6. IF INDIAN, ALLOTTEE OR TRIBE NAME	7. UNIT AGREEMENT NAME	8. FARM OR LEASE NAME Lydia Rentz	9. WELL NO. 4	10. FIELD AND POOL, OR WILDCAT Blanco Pictured Cliff	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec 19, T25N-R3W	12. COUNTY OR PARISH Rio Arriba	13. STATE NM
14. PERMIT NO.	15. ELEVATIONS (Show whether DE, BE, GR, or CR) 7292' KB	16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data										

RECEIVED
MAR 26 1990
OIL CON. DIV
DIST. 3

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF
FRACTURE TREAT
SHOOT OR ACIDIZE
REPAIR WELL
(Other)

PULL OR ALTER CASING
MULTIPLE COMPLETE
ABANDON*
CHANGE PLANE

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF
FRACTURE TREATMENT
SHOOTING OR ACIDIZING
(Other)

REPAIRING WELL
ALTERING CASING
ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Texaco Inc. proposes to complete additional pay in the Picture Cliffs formation. The following procedure will be used:

1. MIRUSU. Install BOP w/pipe and blind rams. TOOH w/tbg.
2. Set CIBP at 5500'. Pressure test to 2200 psi. Run GR-CNL-CCL from 4200-3200'.
3. Perforate 4 squeeze holes at 4100'. Establish rate into squeeze holes w/5 1/2" - 13 3/8" casing annulus open.
4. Set 5 1/2" M.S. EZ drill cement retainer or 5 1/2" packer at 4000'.
5. Pump 75 sx class "G" cement 2/LFL and tail in 2/50 sx class "G" neat. Pull out retainer and reverse circulate.
6. Perforate 4 squeeze holes at 3600'.
7. Set 5 1/2" EZ drill cement retainer or 5 1/2" packer at 3500'.
8. Squeeze perforations w/75 sx class "G" w/LFL and tail in w/50 sx class "G" neat. Reverse circulate.
9. Drill out to 4000' w/ 4 3/4" mill tooth bit. Pressure test to 1000 psi. Drill out cement retainer at 4000'. Pressure test to 1000 psi.

18. I hereby certify that the foregoing is true and correct

SIGNED Alan A. Klever

TITLE Area Manager

DATE 2-22-90

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED

MAR 22 1990

BLM-Farm(6), NMOGCC(3), AAK, MLK

*See Instructions on Reverse Side

FOR

Chief, Branch of
Mineral Resources
Farmington