

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE  
(Other instructions on reverse side)

Form approved.  
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.

1. TYPE OF WELL ☒ GAS WELL ☐ OTHER Dual Completion P.C./Chacra

2. NAME OF OPERATOR  
AMEPADA HESS CORPORATION

3. ADDRESS OF OPERATOR  
Drawer "D", Monument, New Mexico 88265

4. LOCATION OF WELL (Report location clearly and in accordance with all State requirements.  
See Appendix 17 below.)  
At surface  
1650' FSL, 1450' FEL Unit J

14. PERMIT NO.

15. ELEVATIONS (Show whether D.F., RT., G.G., etc.)  
6532' GR

U. S. GEOLOGICAL SURVEY  
FARMINGTON, N. M.

5. LEASE DESIGNATION AND SERIAL NO.  
09-000149

6. IF INDIAN, ALLOTTEE OR TRIBE NAME  
Jicarilla Apache

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME  
J. Apache "F"

9. WELL NO.  
4

10. FIELD AND POOL, OR WILDCAT  
Otero Field

11. SEC., T., R., M., OR BLS. AND  
SURVEY OR AREA  
18, 25N, 5W

12. COUNTY OR PARISH  
Rio Arriba

13. STATE  
NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	<input type="checkbox"/>	WATER SHUT-OFF	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	FRACTURE TREATMENT	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>	SHOOTING OR ACIDIZING	<input type="checkbox"/>
REPAIR WELL	<input checked="" type="checkbox"/>	(Other)	<input type="checkbox"/>
OTHER	<input type="checkbox"/>	(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)	<input type="checkbox"/>
FULL OR ALTER CASING	<input type="checkbox"/>	REPAIRING WELL	<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>	ALTERING CASING	<input type="checkbox"/>
ABANDON*	<input type="checkbox"/>	ABANDONMENT*	<input type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>		

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting, any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

1. Pull 3/4" siphon string and 2-3/8" tubing from Model "D" at 3428'.
2. Set RBP at 2600' and test 5-1/2" casing. Isolate leak if casing does not test and pump enough Class "H" cement to get a good squeeze. Drill out and test.
3. If no hole is found in casing, perforate with two shots at 275' (50' below surface casing shoe) and pump Class "H" cement until returns are seen at the surface or until a maximum of 100 sacks have been pumped. Drill out and test.
4. Swab casing dry and retrieve bridge plug.
5. Run 2-3/8" tubing with a sliding sleeve and set in Model "D" at 3428'. Place on production and re-schedule packer leakage test.

18. I hereby certify that the foregoing is true and correct

SIGNED R. W. Holmes TITLE Petroleum Engineer DATE May 27, 1983

(This space for Federal or State office use)

APPROVED BY  
CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED  
DATE  
1983  
JAMES F. SIMS  
DISTRICT ENGINEER

\*See Instructions on Reverse Side

WACCC