

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. <i>30-037-06091</i>
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name <i>Nazarene Church</i>
8. Well No. <i>11-C</i>
9. Pool name or Wildcat <i>Pictured Cliffs</i>
10. Elevation (Show whether DP, RKB, RT, GR, etc.)

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER	2. Name of Operator <i>Michael A Gold</i>
3. Address of Operator <i>3269 N. Knoll Dr. Los Angeles Calif. 90068</i>	4. Well Location Unit Letter <i>D</i> : <i>1190</i> Feet From The <i>North</i> Line and <i>925</i> Feet From The <i>West</i> Line Section <i>11</i> Township <i>25 N</i> Range <i>02 W</i> NMPM <i>Rio Arriba</i> County
10. Elevation (Show whether DP, RKB, RT, GR, etc.)	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

SEE ATTACHED PROCEDURE

RECEIVED
APR 22 1990
OIL CON. DIV.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE *Randy Blackmon for Michael Gold* TITLE _____ DATE *4-21-98*
TYPE OR PRINT NAME *Randy Blackmon* TELEPHONE NO. *327-4435*

(This space for State Use)

APPROVED BY *Johnny Robinson* TITLE *DEPUTY OIL & GAS INSPECTOR, DIST. #3* DATE *APR 22 1998*
CONDITIONS OF APPROVAL, IF ANY:

PLUG & ABANDONMENT PROCEDURE

**Nazarene Church # 11C
Pictured Cliffs
Section 11, T 25N, R 02W
Rio Arriba, New Mexico**

Note: All cement volumes use 100% excess outside pipe and 50' excess inside. The stabilizing wellbore fluid will be 8.3 ppg, sufficient to balance all exposed formation pressures.

1. Install and test location rig anchors. Prepare blow pit. Comply to all NMOCD, BLM, and MOI regulations.
2. MOL and RU daylight pulling unit. Conduct safety meeting for all personnel on location. NU relief line. Blow down well and kill with water as necessary. ND wellhead and NU BOP. Test BOP.
3. TOOH and tally 1-1/4" tubing. RU wireline unit. RIH with 4.5" gauge ring to 3450'. RIH with 4.5" CIBP & set @ 3450'. Load hole & pressure test 4.5" casing to 500 psi. TIH with tubing & tag CIBP.
4. **Plug #1 (Pictured Cliffs, Fruitland, Kirtland, & Ojo Alamo tops 3140' to 3450').** Mix and pump 25 sx balanced cement plug. POOH.
5. **Plug #2 (Nacimiento top 2250' to 2350').** Perforate 2 holes @ 2350'. Establish rate into perforations. RIH with tubing to 2200'. Mix and pump 50 sx class B cement. Displace tubing capacity. Lay down 10 jts of tubing and WOC. Tag plug and TOOH.
Note: If casing doesn't pressure test, a 4.5" cement retainer will be set at 2300'. Pump 43 sx cement below retainer. Sting out and place 7 sx above retainer.
6. **Plug #3 (130' to Surface).** Perforate 2 holes @ 130'. Establish circulation out bradenhead. Mix and pump class B cement until good returns are visible at surface (approximately 31 sx). WOC.
7. ND BOP and cut off wellhead below surface casing collar. Install P&A marker to comply with regulations. RD, MOL, cut off anchors, and restore location.


Recommended: 

Nazarene Church #11C

CURRENT
Pictured Cliffs .

Section 11, T-25-N, R-2-W, Rio Arriba County, NM

Today's Date: 04/14/98
Spud Date: 7-13-56
Completion Date: 8-10-56



Nazarene Church #11C

PROPOSED
Pictured Cliffs .

Section 11, T-25-N, R-2-W, Rio Arriba County, NM

Today's Date: 04/14/98
Spud Date: 7-13-56
Completion Date: 8-10-56

