

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

Copies

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

| | | |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|--------------------------------------------------------------------|
| 1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/> | | 5. LEASE DESIGNATION AND SERIAL NO. NM-0557389 |
| 2. NAME OF OPERATOR BCO, Inc. | | 6. IF INDIAN, ALLOTTEE OR TRIBE NAME |
| 3. ADDRESS OF OPERATOR P. O. Box 669 Santa Fe, New Mexico 87501 | | 7. UNIT AGREEMENT NAME |
| 4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 990 FSL and 1793 FWL Sec 12 T24N R 8W | | 8. FARM OR LEASE NAME Nancy |
| 14. PERMIT NO. | | 9. WELL NO. 3 |
| 15. ELEVATIONS (Show whether DF, RT, GR, etc.) GL 7202 | | 10. FIELD AND POOL, OR WILDCAT Undes Mancos Dakota |
| | | 11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA 12-24N-8W NMPM |
| | | 12. COUNTY OR PARISH San Juan |
| | | 13. STATE New Mexico |

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(Other) Perforate & frac

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Drill out bridge plug, set at 7,020 feet.
2. Set cement retainer at 7,100 feet and plug lower Dakota with 50 sacks cement.
3. Log cement and perforate Skelly
4. Isolate perforations from 7,074 feet to 7,078 feet & sand water gel frac.
5. Isolate perforations from 7,029 feet to 7,056 feet & sand water gel frac.
6. Isolate perforations from 6,948 feet to 6,964 feet & sand water gel frac.
7. Set retrievable bridge plug below Skelly and above Mary & sand water gel frac Skelly.
8. Remove retrievable bridge plug & place well back into operation.

18. I hereby certify that the foregoing is true and correct

SIGNED

Harry L. Ziegler

TITLE

Chairman

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

8/5/76

*See Instructions on Reverse Side

U. S. GEOLOGICAL SURVEY
WASHINGTON, D. C.