

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> Dry Hole	5. LEASE DESIGNATION AND SERIAL NO. Contract #117
2. NAME OF OPERATOR Consolidated Oil & Gas, Inc.	6. IF INDIAN, ALLOTTEE OR TRIBE NAME Jicarilla Apache
3. ADDRESS OF OPERATOR 1860 Lincoln Street, Denver, Colorado 80295	7. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 790' FSL & 1850' FEL	8. FARM OR LEASE NAME Jicarilla
	9. WELL NO. 5
	10. FIELD AND POOL OR WILDCAT Japacita NE east of Blanco Mesaverde
	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 34, T26N, R3W NMPM
14. PERMIT NO.	12. COUNTY OR PARISH Rio Arriba
15. ELEVATIONS (Show whether DF, RT, GR, etc.)	13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>	WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETE <input type="checkbox"/>	FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input checked="" type="checkbox"/>	SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	(Other) <input type="checkbox"/>	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

After completion attempts in Mesaverde and Pictured Cliff, well has been shut in for pressure buildup on Pictured Cliff. 800 psi recorded. Well will blow down in 10 mins. with volume too small to measure.

The following is the intended plugging procedure:

1. Set cement retainer at 5550' and squeeze perfs from 5630'-6206' with 150 sx. cement.
2. Spot cement plug from 3900' to 4050' (perfs 3970'-3990') using 50 sx. cement.
3. Shoot casing (7" 23#) off at 3700'± (base of Ojo Alamo) and spot 50 sx. plug from 3700' to 3550' (est. 70' above Ojo Alamo top).
4. Pull 7" casing and spot 50 sx. plug from 380' to 275' to cover surface casing shoe.
5. Spot 10 sx. plug in top of surface casing.
6. Erect dry hole marker.

18. I hereby certify that the foregoing is true and correct

SIGNED D. T. Stogner, Jr. TITLE Chief Drilling and Production Engineer

DATE 1/18/78

(This space for Federal or State office use)

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

DATE _____

1978