

DRILLING SCHEDULE - JICARILLA 101 #7 (Page 2)

Cementing:

9 5/8" surface casing - 110 sacks of Class "B" with 3% CaCl_2 (130 cu. ft.).
WOC for 12 hours. Test to 600 psi before drilling out.

7" intermediate casing - 270 sacks 50/50 poz with 6% gel and .6% Halad 9
(12.8 PPG) followed by 70 sacks of Class "B" with
2% CaCl_2 and .6% Halad 9 (468 cu. ft.). Run temp.
survey after 8 hours. WOC for 12 hours and test to
1000 psi before drilling out.

4 1/2" liner - Precede cement with 40 bbl. gelled water. Cement with 450 sacks
50/50 poz with 6% gel, .6% fluid loss additive and .3% retarder
(666 cu. ft. - 50% excess to circulate liner).

6-29-78