

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-73

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL <input type="checkbox"/>	GAS WELL <input checked="" type="checkbox"/>	OTHER-
Name of Operator Kenai Oil & Gas Inc.		
Address of Operator 1675 Larimer St. Suite 500 Denver, CO. 80202		
Location of Well UNIT LETTER <u>B</u> <u>1190</u> FEET FROM THE <u>North</u> LINE AND <u>1460</u> FEET FROM THE <u>East</u> LINE, SECTION <u>28</u> TOWNSHIP <u>26N</u> RANGE <u>2W</u> NMPM.		

7. Unit Agreement Name
8. Farm or Lease Name Evans - 28
9. Well No. 31
10. Field and Pool, or Wildcat Blanco Mesaverde
12. County Rio Arriba

15. Elevation (Show whether DF, RT, GR, etc.)  
7410' KB

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
WELL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Lower tubing to PBTD (6098') and circulate hole with 8.6#/gal mud.
- 2) Spot 75 sxs. cement plug in 4 1/2", 10.5# csg. from PBTD to ± 5200'.
- 3) Spot 50 sxs. cement in 4 1/2", 10.5# csg. from 3900 to ± 3300'.
- 4) POOH & lay down 2 3/8" tbq.
- 5) Cut 4 1/2" csg. at free point (est. 2500').
- 6) Spot 50 sxs. plug thru 4 1/2" on top of 4 1/2" stub.
- 7) Spot 130 sxs. plug from 400' to surface.
- 8) Cut off wellhead and install marker.

RECEIVED  
AUG 31 1983  
OIL CON. DIV.  
DIST. 3

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Don Jones TITLE Production Manager DATE 8/30/83

Original Signed by CHARLES GHOLSON

DEPUTY OIL & GAS

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: