

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPPLICATE  
(Other instructions on reverse side)

Form approved.  
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

5. LEASE DESIGNATION AND SERIAL NO.  
SF 079395 NM 41653

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME  
Federal "C"

9. WELL NO.  
#1

10. FIELD AND POOL, OR WILDCAT

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA  
Sec. 34, T25N, R10W

12. COUNTY OR PARISH  
San Juan

13. STATE  
New Mexico

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Elliott Oil Company

3. ADDRESS OF OPERATOR

c/o Henry Production, Inc.

P. O. Box 2177, Farmington, New Mexico 87401

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface

990' from south, 1980' from west

Sec. 34, T25N, R10W NMFM

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

6804

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

1. Set 30 sx cement. Plug from TD to 5250'.
2. Pulled tubing, perforated 4 holes at 4500'.
3. Run Halliburton cement retainer on tbg set at 4300'. Pumped 50 sx cement. Plug below retainer. Pulled tubing.
4. Perf 4 holes at 1800'. Run Halliburton cement retainer. Set at 1500'. Pumped 75 sx cement plug blow retainer. Pulled tubing.
5. Shot casing off at 1150'. Spotted 45 sx plug on casing stub and pulled casing.
6. Spot plugs. 70 sx at 450' to 200'.
7. Installed P & A marker with 10 sx. Plug.
8. Clean location. Fill pit. Clean battery location and drill grass seed.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Agent

DATE 8-21-79

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

APPROVED  
DEC 14 1982  
JAMES F. SIMS  
DISTRICT ENGINEER

\*See Instructions on Reverse Side